




**FRIEDEMANN
WAGNER**
Handhabungstechnik

Installation and Operating Instructions

Linear Unit

Type: LEN; VEN; ZWP





Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Internet: <http://www.wagnerautomation.de>
Email: info@wagnerautomation.de

Edition 04/2017

Translation of Original Installation and Operating Instructions

		NOTICE
	<p style="text-align: center;"><i>Important! – Read carefully before use – Keep for future reference!</i></p> <p><i>The installation and operating instructions are an integral part of the device and must be available to the operating and maintenance personnel at all times. The safety information contained in them must be heeded accordingly.</i></p> <p><i>If the device is resold, these installation and operating instructions must always be delivered with it as well. The latest version is to be found on the Internet at the manufacturer's website: http://www.wagnerautomation.de</i></p>	

Warranty and guarantee conditions:

See chapter 6.1, Warranty and guarantee conditions.

The **warning and safety symbols** are explained in chapters 3.1 and 3.1.1.

Translation

If the device is sold to a country in the EEA, these installation and operating instructions must be translated into the language of the country in which the device is to be used. Should the translated text be unclear, the original installation and operating instructions (German) must be consulted or the manufacturer contacted for clarification.

Copyright

No part of this publication may be reproduced, transmitted, sold or disclosed without prior permission. Damages will be claimed for violations.

All rights reserved.

Document name:

[Dss737 BA_722_Lineareinheit-LEN_VEN_ZWP-04_08_2016_Druckversion gez_7_2016.doc](#)

1 Contents

1.1 Table of contents

1	Contents	3
1.1	Table of contents	3
1.2	Table of figures	4
1.3	List of tables	4
1.4	Declaration of incorporation	5
2	Overview and intended use	6
2.1	Overview of the device	6
2.2	Intended use	7
2.2.1	Product identification	8
2.2.2	Incorporation information (for the partly completed machinery) for the constructor of the final machinery	8
2.3	Technical data	9
2.3.1	Dimensions and weight	9
2.3.2	Environmental conditions	10
2.3.3	Characteristics and allowable loads	11
2.3.4	General data	13
3	Safety	13
3.1	Notes and explanations	13
3.1.1	Explanation of safety symbols used	14
3.2	Safety precautions (to be carried out by the operator)	15
3.3	Safety inspections and tests	15
4	General warnings	16
4.1	Dangers	16
4.2	Spare and wearing parts	17
5	Installation	18
5.1	Scope of delivery	18
5.2	Transport and packaging	19
5.2.1	Delivery (also of spare and replacement parts)	19
5.2.2	Temporary storage/Storage conditions	19
5.3	Mounting	20
5.3.1	Mounting of the linear unit	20
5.3.2	Mounting of the ZWP-VEN-6 intermediate position unit	21
5.3.3	Mounting of superstructures	24
5.3.4	Connection examples	25
5.3.4.1	Example of standard pneumatic connection	25
5.3.4.2	Example of pneumatic connection with EMERGENCY STOP circuit	26
5.3.5	Adjustment possibilities for the linear unit	27
5.3.5.1	Set speed	28
5.3.5.2	Set shock absorber	29
5.4	Startup	31
5.4.1	Mounting and connection of proximity switches (partly accessories)	32
5.4.2	Connection of the integrated proximity switches	34

5.4.3	Repair / Replacement of the hydraulic shock absorber	35
5.4.4	Air grommets	37
5.4.5	Electric signal grommets	39
6	Maintenance/Service	41
6.1	Warranty and guarantee conditions	42
7	Troubleshooting	43
8	Dismantling / Disposal	44
9	Spare part lists and accessories	45
9.1	Spare part lists	45
9.2	Accessories	48

1.2 Table of figures

Fig. 2-1	Diagram of the parts of the linear unit	6
Fig. 2-2	Characteristics and loads	12
Fig. 5-1	Scope of delivery of the device	18
Fig. 5-2	Possible motion sequences with intermediate position unit	21
Fig. 5-3	Mounting of the ZWP-VEN-6 intermediate position unit	22
Fig. 5-4	Mounting and mounting of superstructures	24
Fig. 5-5	Standard circuit	25
Fig. 5-6	Emergency stop circuit	26
Fig. 5-7	Adjustment possibilities for the linear unit	28
Fig. 5-8	Mounts for shock absorbers	30
Fig. 5-9	Set shock absorber for STD-14	30
Fig. 5-10	Mounting and connection of proximity switches	33
Fig. 5-11	Connection of the integrated proximity switches	34
Fig. 5-12	Connection diagram for proximity switches	35
Fig. 5-13	Repair / Replacement of the hydraulic shock absorber	36
Fig. 5-14	Air grommets	38
Fig. 5-15	Electric signal grommets	40
Fig. 9-1	Spare part list	47

1.3 List of tables

Table 1	Troubleshooting	43
---------	-----------------	----

1.4 Declaration of incorporation

Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Declaration of incorporation

pursuant to the

- **EC Machinery Directive 2006/42/EC**
- **EC EMC Directive 2014/30/EU**

We hereby declare that the design of the

Designation: Linear Unit

Type: LEN-6-X-X-H-X-X-P / VEN-6-X-X-H-X-X-P / ZWP-6-VEN

as delivered complies with the above directives.

Harmonized DIN EN standards applied pursuant to the Official Journals for the directives:

Directive / Standard	Title
DIN EN ISO 82079-1 :2012	Preparation of instructions for use – Structuring, content and presentation – Part 1: General principles and detailed requirements
2006/42/EC	EC Directive: Machinery <i>effective from 2009-12-29</i>
DIN EN ISO 12100 :2010	Safety of machinery – General principles for design – Risk assessment and risk reduction

- This declaration only applies to the linear unit in the state in which it was placed on the market.
- The essential health and safety requirements according to Annex I of the Machinery Directive were applied and are fulfilled.
- The following chapters in Annex I of the Machinery Directive 2006/42/EC were considered in the risk assessment:
1.1.2, 1.1.3, 1.1.5, 1.2.6, 1.3.1, 1.3.2, 1.3.3, 1.3.4, 1.3.6, 1.3.7, 1.3.8.2, 1.3.9,
1.4.1, 1.4.2.1, 1.5.3, 1.5.4, 1.5.9, 1.5.11, 1.5.15, 1.6.1, 1.6.4, 1.7.1, 1.7.2, 1.7.3, 1.7.4.
- The special technical file according to Annex VII B was compiled and will be presented to the competent national authorities in electronic form on demand.
- **The linear unit may not be put into service until the final machinery into which it is incorporated has been declared in conformity with the provisions of the directives.**
- The person authorized to compile the technical documentation is:
Name: Mr. Andreas Wagner
Address: Robert-Bosch-Straße 5, D-78559 Gosheim / Germany

Gosheim, April 2017

Authorized Signature
(A. Wagner, Managing Director)

2 Overview and intended use

2.1 Overview of the device






Fig. 2-1 Diagram of the parts of the linear unit

The LEN / VEN / ZWP linear unit consists of the following main components:	
(A) Head plate (B) Bores for fastening with centering rings (C) Connection plate (D) Guide head (E) Guide shafts (F) Centering rings (G) Hydraulic shock absorber	(H) Lock nuts for the stop screws (I) Stop screws (K) Position of the proximity switches (L) Air grommets (M) Signal grommets (N) Cover (O) Cover plate for VEN (option) (P) End plate

2.2 Intended use



The linear units were developed to move components or superstructures a defined distance horizontally or vertically. They are suitable for positioning in assembly work or processing of components.

This device was developed, designed and built exclusively for industrial and light-industrial use. Private use is prohibited.

	 DANGER
	<p><i>This device is intended solely for the purpose described above. Any other use or modification of the device without the written consent of the manufacturer is deemed improper.</i></p> <p><i>Modification without written agreement will lead to serious to deadly injuries.</i></p> <p><i>The manufacturer accepts no liability for resultant damage. The risk is borne solely by the operator. The device may only be put into operation when it has been ensured that all safety devices have been installed and are fully functional.</i></p>

Proper use of the device in accordance with its intended purpose includes compliance with the manufacturer's instruction handbooks and operating manuals and performance of all specified maintenance and service work.

Foreseeable misuse:

	 NOTICE
	<p><i>Products that could form explosive dust/air or gas/air mixtures may not be processed in critical concentrations (above LEL)!</i></p> <p><i>The device does not fulfil any EX requirements and may therefore also not be installed and operated in ATEX zones!</i></p> <p><small>*) LEL = Lower Explosive Limit</small></p>

The device is not suitable for use in machining operations, especially of aluminum, titanium and magnesium, as, depending on product compositions, particle sizes, chip sizes and distribution of quantities, potentially explosive atmospheres can result. The final decision on use lies in the end user's judgment.

Linear Unit Type: LEN; VEN; ZWP

2.2.1 Product identification

The type key is laser-engraved on the connection side of the linear unit. The following table explains the type key:

Module	Design size	Version	Stroke	Shock absorber	Energy feedthrough	Drive
LEN	6	I B	100 200 300 400	H	0-0 6-0 6-6	-P
VEN	6	I B	60 120 180 240 300	H	0-0 4-0 4-4	-P
ZWP	6	VEN	60 120 180 240 300	H	4-0	-P
Linear units Intermediate positions		I=integration B=basic model VEN=only for VEN		H hydraulic	0- pneumatic -0 electric	-P pneumatic

2.2.2 Incorporation information (for the partly completed machinery) for the constructor of the final machinery

- Control is effected via a 4/2 or 5/2 directional-control valve (not included in the delivery).
- The threaded bores and centering rings enable easy mounting.
- The speed can be adjusted freely with an external exhaust regulator (not included in the delivery).
- Completely equipped for immediate use.
- Use of the units LEN-6 and VEN-6 for “pick and place” applications.
- Movement to a third position via ZWP-6 intermediate position unit.

After considering the above points, the integrator of the final machinery can put this device into service as a safe device.

Linear Unit Type: LEN; VEN; ZWP

He must supply overall instructions for use and a declaration of conformity for the complete machinery and affix a type plate with CE marking to the machinery. The responsibility for the risk assessment for the complete machinery lies internally with the integrator.

2.3 Technical data

2.3.1 Dimensions and weight

	LEN-6-B-X-H-0-0-P	LEN-6-I-X-H-6-0-P	LEN-6-I-X-H-6-6-P	VEN-6-B-X-H-0-0-P	VEN-6-I-X-H-4-0-P	VEN-6-I-X-H-4-4-P	ZWP-6-VEN-X-H-4-0-P
Guide	4 linear bushings, sealed on hardened, ground steel shafts			4 linear bushings, sealed on hardened, ground steel shafts			-
Version	Fully equipped			Fully equipped			
Stop	Face			Face			
Cover	●			●			-
Energy feedthrough	-	Air	Air/Signal	-	Air	Air/Signal	Air
Energy feedthrough	0-0	6-0	6-6	0-0	4-0	4-4	4-0
Stroke lengths [mm]	100/200/300/400			60/80/120/240/300			
Adjustment range [mm]	19 mm (retracted) 30 mm (extended)			14 mm (retracted) 34 mm (extended)			Complete way
Type							
Repeatability [mm]	±0.02						±0.03
Push force at 6 bar [N]	210			150			-
Retraction force at 6 bar [N]	140			85			-
Shock absorbers hydraulic	●			●			●
Cylinder Ø [mm]	25			20			16
Drive	Compressed air (4-8 bar), constant, filtered (10 µm) and dry						
Connection	M5						
Control	4/2; 5/2 directional-control valve, bistable						
Housing material	High strength aluminum, anodized						
Stop system material	Steel						

○ Option / ● Included in delivery

Linear Unit Type: LEN; VEN; ZWP

Module	LEN-6-B-X-H-0-0-P				LEN-6-I-X-H-6-0-P LEN-6-I-X-H-6-6-P			
	100	200	300	400	100	200	300	400
Stroke length [mm]	100	200	300	400	100	200	300	400
Weight [kg]	6	7.1	8.2	9.3	6.5	7.6	8.7	9.8
Air consumption double stroke [cm ³]	98.2	196	295	393	98.2	196	295	393
Max. payload [kg]	20	15	12	9	20	15	12	9

Module	VEN-6-B-X-H-0-0-P					VEN-6-I-X-H-4-0-P VEN-6-I-X-H-4-4-P				
	60	120	180	240	300	60	120	180	240	300
Stroke length [mm]	60	120	180	240	300	60	120	180	240	300
Weight [kg]	2.2	2.8	3.1	3.7	3.9	2.8	3.2	3.7	4.1	4.5
Air consumption double stroke [cm ³]	37.7	75.4	113	151	189	37.7	75.4	113	151	189
Max. payload [kg]	11	10	9	8	7	11	10	9	8	7








Module	ZWP-6-VEN-X-H-4-0-P				
Stroke length [mm]	60	120	180	240	300
Weight [kg]	1.24	1.26	1.28	1.3	1.32
Air consumption double stroke [cm ³]	8	8	8	8	8
Max. payload [kg]	11	10	9	8	7








2.3.2 Environmental conditions

- Operation only in closed rooms and low-vibration environments (no potentially explosive or condensing atmospheres).
- No operation in environments with spray water, vapors, process dusts or abrasion dusts.
- Linear units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.
- The linear units are only suitable for use in environments with spray water to a limited extent. It might be necessary to protect them against ingressing spray water with a suitable cover.

Linear Unit Type: LEN; VEN; ZWP

2.3.3 Characteristics and allowable loads

LEN-6																					
	Lineareinheit LEN-6--100/200/300/400	Zulässige Belastungen statisch/dynamisch Allowable loads static/dynamic																			
		M01zul [Nm]	M02zul [Nm]	M03zul [Nm]	C _{st/dyn} [N]	A [mm]	B [mm]	C [mm]													
		118/174	118/174	62/91	1981/2911	74+Hub	37	23													
<div><div><p>M01=(A+L1) x F01</p></div><div><p>M02=(A+L2) x F02</p></div><div><p>M03=(B+L3) x F03</p></div><div><p>M01=(C+L1) x F01</p></div><div><p>M02=(B+L2) x F02</p></div><div><p>M03=(C+L3) x F03</p></div></div> <div><div>Lebensdauerberechnung mit Momenten Lifetime calculation with moments</div><div>$L = \left(\frac{M_{zul}}{M_{eff}} \right)^3 \times 10^5$</div></div> <div><div>Lebensdauerberechnung mit Kräften Lifetime calculation with forces</div><div>$L = \left(\frac{C}{F} \right)^3 \times 10^5$</div></div> <table><tr><td>L</td><td>Lebensdauer [m]</td><td>lifetime [m]</td></tr><tr><td>M_{zul}</td><td>zulässiges Moment [Nm]</td><td>allowable moment [Nm]</td></tr><tr><td>M_{eff}</td><td>effektives (benötigtes) Moment [Nm]</td><td>effective (needed) moment [Nm]</td></tr><tr><td>C</td><td>dynamische Tragzahl [N]</td><td>dynamic load rating [N]</td></tr><tr><td>F</td><td>dynamische Belastung [N]</td><td>dynamic load force [N]</td></tr></table> <div>Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein: In combined loads situations the next equation must be met:</div> <div>$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$</div>							L	Lebensdauer [m]	lifetime [m]	M _{zul}	zulässiges Moment [Nm]	allowable moment [Nm]	M _{eff}	effektives (benötigtes) Moment [Nm]	effective (needed) moment [Nm]	C	dynamische Tragzahl [N]	dynamic load rating [N]	F	dynamische Belastung [N]	dynamic load force [N]
L	Lebensdauer [m]	lifetime [m]																			
M _{zul}	zulässiges Moment [Nm]	allowable moment [Nm]																			
M _{eff}	effektives (benötigtes) Moment [Nm]	effective (needed) moment [Nm]																			
C	dynamische Tragzahl [N]	dynamic load rating [N]																			
F	dynamische Belastung [N]	dynamic load force [N]																			

VEN-6																					
	Lineareinheit VEN-6--100/200/300/400	Zulässige Belastungen statisch/dynamisch Allowable loads static/dynamic																			
		M01zul [Nm]	M02zul [Nm]	M03zul [Nm]	C _{st/dyn} [N]	A [mm]	B [mm]	C [mm]													
		60/91	60/91	38/58	1624/2469	50+Hub	24	42													
<div><div><p>M01=(A+L1) x F01</p></div><div><p>M02=(A+L2) x F02</p></div><div><p>M03=(B+L3) x F03</p></div><div><p>M01=(B+L1) x F01</p></div><div><p>M02=(C+L2) x F02</p></div><div><p>M03=(C+L3) x F03</p></div></div> <div><div>Lebensdauerberechnung mit Momenten Lifetime calculation with moments</div><div>$L = \left(\frac{M_{zul}}{M_{eff}} \right)^3 \times 10^5$</div></div> <div><div>Lebensdauerberechnung mit Kräften Lifetime calculation with forces</div><div>$L = \left(\frac{C}{F} \right)^3 \times 10^5$</div></div> <table><tr><td>L</td><td>Lebensdauer [m]</td><td>lifetime [m]</td></tr><tr><td>M_{zul}</td><td>zulässiges Moment [Nm]</td><td>allowable moment [Nm]</td></tr><tr><td>M_{eff}</td><td>effektives (benötigtes) Moment [Nm]</td><td>effective (needed) moment [Nm]</td></tr><tr><td>C</td><td>dynamische Tragzahl [N]</td><td>dynamic load rating [N]</td></tr><tr><td>F</td><td>dynamische Belastung [N]</td><td>dynamic load force [N]</td></tr></table> <div>Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein: By combined loads it must be met next equation:</div> <div>$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$</div>							L	Lebensdauer [m]	lifetime [m]	M _{zul}	zulässiges Moment [Nm]	allowable moment [Nm]	M _{eff}	effektives (benötigtes) Moment [Nm]	effective (needed) moment [Nm]	C	dynamische Tragzahl [N]	dynamic load rating [N]	F	dynamische Belastung [N]	dynamic load force [N]
L	Lebensdauer [m]	lifetime [m]																			
M _{zul}	zulässiges Moment [Nm]	allowable moment [Nm]																			
M _{eff}	effektives (benötigtes) Moment [Nm]	effective (needed) moment [Nm]																			
C	dynamische Tragzahl [N]	dynamic load rating [N]																			
F	dynamische Belastung [N]	dynamic load force [N]																			




Fig. 2-2 Characteristics and loads

2.3.4 General data

Operating temperature range:

Temperature range device:

+ 5° ... + 65° C

Relative air humidity:

max. 70 %, non-condensing

Storage conditions:

Minimum temperature:

- 10° C

Maximum temperature:







+ 50° C



Relative air humidity:

max. 70 %, non-condensing



3 Safety



3.1 Notes and explanations



	<div data-bbox="395 954 480 1021"></div> <div data-bbox="900 965 1031 999">DANGER</div> <p><i>"DANGER" warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise serious injuries or death will result.</i></p>
	<div data-bbox="395 1178 480 1245"></div> <div data-bbox="900 1189 1046 1223">WARNING</div> <p><i>"WARNING" warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise serious injuries or death can result.</i></p>
	<div data-bbox="395 1402 480 1469"></div> <div data-bbox="900 1413 1038 1447">CAUTION</div> <p><i>"CAUTION" in combination with the warning symbol warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise minor or light injuries could result.</i></p>
	<div data-bbox="395 1671 480 1738"></div> <div data-bbox="900 1682 1023 1715">NOTICE</div> <p><i>"NOTICE" gives recommendations on how to proceed. Ignoring these recommendations will not lead to personal injuries.</i></p> <p><i>Follow the recommendations to avoid damage to the unit and problems in general!</i></p>



		NOTICE
	<p>References to installation and operating instructions / documentation are marked with a book symbol (see external documentation).</p> <p>Follow the recommendations to avoid damage to the unit and problems in general!</p>	



3.1.1 Explanation of safety symbols used

		DANGER
	<p>Crushing hazards, dangers of injuries to the hands (closing movements of mechanical parts).</p> <p>Ignoring this warning will result in serious injuries or death.</p> <p>Do not carry out any manual work on such parts during movements.</p>	

		WARNING
	<p>Mandatory: Safety boots must be worn.</p> <p>Ignoring this warning could result in serious injuries or death.</p> <p>Take note of the dangers to the lower limbs.</p>	

		WARNING
	<p>Mandatory: Protective gloves must be worn.</p> <p>Ignoring this warning could result in serious injuries or death.</p> <p>Take note of the dangers to the hands.</p>	

		WARNING
	<p>Mandatory: Hands must be washed.</p> <p>Ignoring this warning could result in serious injuries or death.</p> <p>Take note of the dangers due to deficient hygiene.</p>	

		NOTICE
	<p>The environment sign marks actions to protect the environment (warning of environmental pollution, in the chapter Disposal).</p> <p>Damage to the environment will result if ignored.</p> <p>Improper disposal can result in serious damage to the environment.</p>	

3.2 Safety precautions (to be carried out by the operator)

- ▶ The linear units may only be installed, serviced and modified by qualified skilled personnel. This personnel must have read and understood the operating instructions.
- ▶ The energy and compressed air supply must be disconnected from the linear unit before any service, maintenance or modification work. Make sure there are no residual energies present.
- ▶ Only use the linear units if they are in perfect technical condition and do not carry out any unauthorized modifications.
- ▶ The linear units can be heavy. Secure them so that they cannot fall down.
- ▶ In the event of an emergency, malfunction or other irregularity, switch off the linear unit, disconnect it from the energy and compressed air supply and lock against reconnection.
- ▶ Carry out a visual inspection of the compressed air lines regularly. Operation with damaged compressed air lines is prohibited.
- ▶ Make sure that the technical specifications and environmental conditions specified in the product documentation are adhered to.
- ▶ The linear unit may only be operated in accordance with its intended use.
- ▶ Take note of the valid regulations on accident prevention and environmental protection.
- ▶ Implement the safeguards required by EC directives.
- ▶ Pressurize your complete equipment with compressed air slowly to avoid uncontrolled movements.
- ▶ Only put your equipment into service if you are sure that no personnel or foreign objects can be caught by the moving parts.

3.3 Safety inspections and tests



Factory inspections and tests by the manufacturer.

1. Risk assessment according to Machinery Directive 2006/42/EC (to Annex I) and to DIN EN ISO 12100:2010.

4 General warnings

4.1 Dangers

The safety systems and safety instructions described in these installation and operating instructions are to be heeded accordingly.



		DANGER
	<p><i>Pay attention to the possible danger of injuries to the hands and/or body when carrying out adjustment, maintenance and repair work!</i></p> <p><i>Otherwise serious injuries or death will result.</i></p> <p><i>The machine builder must implement safety equipment to ensure safe operation.</i></p>	



4.2 Spare and wearing parts

Spare parts and accessories that have not been supplied by us have also not been tested and approved by us. The fitting and/or use of such products could therefore negatively affect the design characteristics of your device.

We accept no liability whatsoever for damage arising from the use of non-original parts and accessories.

Standard parts can be bought through the specialized trade.

		NOTICE
	<p><i>Part lists and technical data sheets are to be found in the technical reference documents.</i></p> <p><i>Otherwise the unit will be damaged.</i></p> <p><i>Damage can arise if the technical reference documents are ignored.</i></p>	

		NOTICE
	<p><i>Lists of spare parts and wearing parts are to be found in the technical reference documents.</i></p> <p><i>Otherwise the unit will be damaged.</i></p> <p><i>Damage can arise if the technical reference documents are ignored.</i></p>	

Service

When necessary, these parts can be obtained from:

Friedemann Wagner GmbH
 Robert-Bosch-Straße 5
 D-78559 Gosheim / Germany
 Telephone: +49 (0) 7426 / 94900-0
 Fax: +49 (0) 7426 / 94900-9
 Email: info@wagnerautomation.de

5 Installation

5.1 Scope of delivery




Fig. 5-1 Scope of delivery of the device

The scope of delivery comprises:

LEN-6	VEN-6	ZWP-VEN-6
<ul style="list-style-type: none"> Linear unit with sheet metal cover Set of shock absorbers and proximity switches (mounted) 3 pc. M6x30 cylinder head screws in unit LEN-6 for mounting of the unit VEN-6 These installation and operating instructions with declaration of incorporation 4 pc. ZR-6 centering rings Cardboard packaging <p>Version LEN-6-I-X-H-6-6-P:</p> <ul style="list-style-type: none"> Connection cable, 5 m, 10-wire with 12-pole connector 6 pc. connectors, 3-pole 6 pc. O-rings, 3.3 x 2.4 <p>Version LEN-6-B-X-H-0-0-P</p> <ul style="list-style-type: none"> Connection cable, 5 m, 4-wire, with 4-pole connector <p>Version LEN-6-I-X-H-6-0-P</p> <ul style="list-style-type: none"> Connection cable, 5 m, 4-wire, with 4-pole connector 6 pc. O-rings, 3.3 x 2.4 	<ul style="list-style-type: none"> Linear unit with sheet metal cover Set of shock absorbers and proximity switches (mounted) These installation and operating instructions with declaration of incorporation 4 pc. ZR-6 centering rings Cardboard packaging <p>Version VEN-6-I-X-H-4-4-P:</p> <ul style="list-style-type: none"> Multiway connectors (mounted) 6 pc. O-rings, 3.3 x 2.4 	<ul style="list-style-type: none"> Cylinder block Counterplate with mounted shock absorber Threaded rod, preassembled Front plate These installation and operating instructions with declaration of incorporation 8 pc. ZR-6 centering rings Cardboard packaging 3 pc. M6x70 cylinder head screws 16 pc. O-rings, 3.3 x 2.4

5.2 Transport and packaging

The customer is sent a specification of the scope of delivery before shipment begins. It contains details on:

- date of delivery,
- number and type of transport units.

The devices are carefully inspected and packed before shipment, but it is nevertheless still possible that they might become damaged during transit.

5.2.1 Delivery (also of spare and replacement parts)

Receiving inspection:

- Check the shipment against the delivery note to ensure that it is complete!

If the packaging is damaged

- Check the shipment itself for damage (visual inspection)!

Complaints

If the shipment was damaged during transit:

- Immediately contact the last carrier!
- Keep the packaging material (for possible inspection by the carrier or for return shipment).



Packaging for return shipment

Use the original packaging material as far as possible.

5.2.2 Temporary storage/Storage conditions

The freight packaging of the device and spare and replacement parts is designed for a storage period of 3 months from delivery.

After dismantling of the device, it must be stored properly to enable reuse.



		NOTICE
	<p><i>Temporary storage: Store with desiccant in a dry factory hall.</i></p> <p><i>Otherwise the unit will be damaged.</i></p> <p><i>Moisture could penetrate into the device and cause major damage.</i></p>	

Linear Unit Type: LEN; VEN; ZWP



Storage conditions

- No direct sunlight.
- No exposure to direct rain, condensation, water.



5.3 Mounting







		WARNING
	<p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

5.3.1 Mounting of the linear unit



		WARNING
	<p><i>When mounting in a vertical position, the slide must always be moved to bottommost position before mounting.</i></p> <p><i>Otherwise light to serious injuries can result from sudden moving masses.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

- ▶ Place at least 2 diagonally offset centering rings (F) (are included in the delivery) in the holes (B) provided.
- ▶ Screw the VEN-6 tight with screws.
- ▶ There is a stand available as accessory for mounting of the LEN-6-X.

		NOTICE
	<p>If the linear unit is mounted vertically, it must be checked whether the push force and end-position damping suffice for the respective application in question.</p>	

		NOTICE	
	<i>The linear units can also be mounted upright. If used as such, note the allowable loads specified in chapter 2.3.3.</i>		
	Normal mode		Portal mode (only VEN-6)
			

5.3.2 Mounting of the ZWP-VEN-6 intermediate position unit

		WARNING
	<i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i>	
	<i>Otherwise light to serious injuries can result.</i>	
<i>Avoid these dangerous situations!</i>		

The intermediate position unit makes it possible to move to a third position in the application for VEN-6.




Fig. 5-2 Possible motion sequences with intermediate position unit

The intermediate position unit is delivered dismantled, cf. chapter 5.1 Scope of delivery. To mount the 3 units LEN, VEN and ZWP, proceed as follows:






Fig. 5-3 Mounting of the ZWP-VEN-6 intermediate position unit

- Remove the cover (1) of the LEN-6. Place the enclosed M6x70 screws (3) through the through holes of the head plate (2) of the LEN-6*.
- Place the centering rings (9) in the head plate of the LEN-6 and place the cylinder block (4) of the ZWP over the protruding screws.
- Place the centering rings (9) in the guide head (17) of the VEN-6 and then fastening the 3 elements by tightening the screws. The cylinder block (4) of the ZWP is now fixed in sandwich form.
- Then mount the front plate (7) of the ZWP on the head plate (16) of the VEN-6.
- Adjust the stroke roughly with the help of the middle two hexagonal nuts (6+10) (size 17 and 13) before mounting. Impact is from above on the stop surface (8).

Linear Unit Type: LEN; VEN; ZWP



- ▶ Then insert the threaded rod (5) first into the front plate (7) and then into the counterplate (13) with mounted shock absorber (12).
- ▶ Mount the counterplate (13) on the end plate (18) of the VEN-6.
- ▶ Later use the upper stop of the toroidal area (11) for fine adjustment (+/- 1.5 mm).
- ▶ If the stroke needs to be changed beyond fine adjustment, it might be necessary in the case of ZWP-6-VEN-60 to dismount the counterplate (13) to readjust the stroke.
- ▶ From a free stroke of 120 mm, the stop nuts (6+10) that need to be adjusted can be reached by moving the guide head (17).
- ▶ Set the end-position damping if necessary (cf. separate chapter 5.3.5.2).

* If the ZWP is used without LEN, an own mounting possibility must be fabricated, possibly with other screws. A cover plate VSP-6-VEN is available as accessory for this case of application in order to close the air grommets.

		NOTICE
	<p><i>If a centering ring is stuck in a hole, you can remove it from the hole easily with a threaded screw. The centering rings have an internal thread specifically for this purpose. Simply screw a suitable screw into the thread of the centering ring and pull the screw plus centering ring out of the hole.</i></p>	

Centering ring	Internal thread
ZR-4	M5
ZR-6	M8
ZR-9	M10

5.3.3 Mounting of superstructures

		WARNING
	<p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

- Fasten the superstructures with screws (19) in the threaded holes with the centering rings (9) provided.










Fig. 5-4 Mounting and mounting of superstructures

Linear Unit Type: LEN; VEN; ZWP

5.3.4 Connection examples

		WARNING
	<p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

		NOTICE
	<p>The following figures show connection examples and illustrate how the linear unit can be connected.</p>	

		NOTICE
	<p><i>A function check must be carried out with compressed air after connection.</i></p>	

5.3.4.1 Example of standard pneumatic connection








Fig. 5-5 *Standard circuit*

- Compressed air connection A (extend)
- Compressed air connection B/F (retract)
- 5/2 control valve, bistable

5.3.4.2 Example of pneumatic connection with EMERGENCY STOP circuit

		WARNING
	<p><i>In the event of a sudden loss of pressure the payload can drop uncontrolled into one end position. To prevent this, piloted non-return valves are recommended.</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Avoid these dangerous situations!</i></p>	

		NOTICE
	<p><i>Please note that suitable emergency stop systems (e.g. systematic shutdown) and restart systems (e.g. correct valve switching sequence, pressure buildup valves) are needed for pneumatic actuators. Unwanted blocking of the compressed air supply can lead to unwanted situations.</i></p>	







Fig. 5-6 Emergency stop circuit

- A. Compressed air connection A (extend)
- B. Compressed air connection B/F (retract)
- 1. 5/2 control valve, bistable
- 2. 3/2 control valve, monostable / emergency stop
- 3. Piloted non-return valve

5.3.5 Adjustment possibilities for the linear unit

- The device is always delivered in its respective “maximum stroke” setting. To adjust, proceed as follows:
- Dismount the cover.

<p>LEN-6</p> 	 <ul style="list-style-type: none"> ► The stop system works by way of two stop screws (2), which are locked differently with nuts (6) for design reasons. ► Loosen the hexagonal nuts (6), turn the stop screw in or out and then lock the stop screw against the head plate (2) and end plate (21) with the hexagonal nuts (6).
<p>VEN-6</p> 	<ul style="list-style-type: none"> ► The stop system works by way of hexagonal stop screws (20), each of which is locked with a nut (6). ► Loosen the hexagonal nut (2), turn the stop screw in or out and then lock the stops again against the head plate (16) and end plate (18) with the hexagonal nut (2).

Linear Unit Type: LEN; VEN; ZWP






Fig. 5-7 Adjustment possibilities for the linear unit



After adjusting the stroke, it might be necessary to readjust the shock absorber, cf. separate chapter 5.3.5.2.

5.3.5.1 Set speed

		WARNING
<p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p>		


The speed can be adjusted to the load by an external exhaust regulator (not included in the delivery). If the regulator is set too fast, this will cause hard stopping and bouncing. This can also have a negative effect on the lifetime of the linear unit and even result in destruction of its mechanical components.

5.3.5.2 Set shock absorber

		WARNING
	<p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p>	

The strength of the shock absorber must be adjusted to the load. If the shock absorber is set too hard, it is possible for the linear unit to bounce and it does not reach end position. If the shock absorber is set too soft, this will cause hard stopping and bouncing. This can also have a negative effect on the lifetime of the linear unit and even result in destruction of its mechanical components.

- ▶ Depending on the mass being moved and the speed, there are kinetic energies in the system that are absorbed by hydraulic shock absorbers.
- ▶ The units LEN-6, VEN-6 and ZWP-6-VEN are already equipped in their standard configuration with adjustable hydraulic shock absorbers of the type STD-14-W.
- ▶ To adjust, dismount any covers present.
- ▶ Move the head plate manually to end position and leave it there.

Unit	Mount for shock absorber
<p>LEN-6 / LEN-6</p> 	<ul style="list-style-type: none"> ▶ The mount for the shock absorber (12) is located in the central guide head. The shock absorbers are locked with a hexagonal nut (6).






Fig. 5-8 Mounts for shock absorbers

		NOTICE
	<p><i>The shock absorbers are pre-set on delivery. It is, however, possible that the damping action needs to be set softer or harder.</i></p>	






Fig. 5-9 Set shock absorber for STD-14

Set shock absorber harder

Turn the adjusting screw to the right.



Set shock absorber softer

Turn the adjusting screw to the left.

		NOTICE
	<p><i>Only adjust the damping action with the adjusting screw (STD-14). If the damping action is still too hard even though the adjusting screw is open, the damping action must be adjusted via the shock absorber stroke.</i></p>	









Pressurize the system with compressed air and let the linear unit drive into the end positions. Adjustment is correct when the end positions are reached without visible delay and without bouncing.

5.4 Startup

		WARNING
	<p><i>Risk of injury from moving masses. Make sure that no personnel or foreign objects can be caught by moving parts. Disconnect the linear unit from the compressed air supply.</i></p> <p><i>Otherwise serious injuries or death can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

- ▶ Do not overload the devices.
- ▶ Adjust the stroke length (cf. chapter 5.3.5).
- ▶ Connect all air hoses and signal cables correctly.
- ▶ Pre-set the shock absorbers.
- ▶ Pre-set the sensors.
- ▶ Close all regulators and then open them again by one revolution.
- ▶ Make sure that no personnel or foreign objects can be caught by moving parts.
- ▶ Pressurize your equipment slowly with compressed air.
- ▶ Start a trial run.
- ▶ Set the required speed.
- ▶ Set the shock absorbers.
- ▶ End the trial run.

5.4.1 Mounting and connection of proximity switches (partly accessories)

		WARNING
	<p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	
		NOTICE
	<p><i>The standard ZWP-6-VEN device does not come with proximity switches. However, to query end positions, it is necessary to retrofit proximity switches. The proximity switches can be obtained separately as accessories.</i></p>	
		NOTICE
	<p><i>The linear units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.</i></p>	
		NOTICE
	<p><i>Make sure that the proximity switches do not extend over the stop surface - this can lead to damage and destruction of parts.</i></p>	

Linear Unit Type: LEN; VEN; ZWP



Unit	Mounting/Replacement
<p>LEN-6 / VEN-6</p> 	<p>The proximity switch sets (22) are already mounted in the guide head.</p> <p>If replacement is necessary, take off the cover and loosen the set screws (23). After fine adjustment, clamp the proximity switches again with the set screws (2 Nm).</p> <p>Set the proximity switches so that the LED of the switch lights up when the respective end position is reached. Make sure that the switch signal does not set in too soon because otherwise the linear unit will not reach end position.</p> <p>Due to the very compact construction of VEN-6, there are grooves in the support of the guide head for the cables.</p>
<p>ZWP-6-VEN</p> 	<p>The quadratic proximity switches (24) from the range of accessories are fastened at the corresponding threaded bores (25) with M3x12 screws (26).</p> <p>No further adjustments must be made to these proximity switches.</p> <p>The upper proximity switch reports that the intermediate position has been reached and the proximity switch in the area of the stop reports when the stop has been extended.</p>

Fig. 5-10 Mounting and connection of proximity switches

Linear Unit Type: LEN; VEN; ZWP

5.4.2 Connection of the integrated proximity switches

LEN	VEN
The versions LEN-6-B-X-H-0-0-P and LEN-6-I-X-H-6-0-P have a 4-pole M16x0.75 socket at the connection plate with cable, 5 m including connector, for connection of the integrated proximity switches.	The proximity switches are mounted and equipped with cables with free ends.
The version LEN-6-I-X-H-6-6-P has a 12-pole M16x0.75 at the connection plate with enclosed cable, 5 m with connector, for connection of the integrated proximity switches and the implemented signals.	

Assignment 4-pole socket

Initiator eingefahren
Initiator retracted

Initiator ausgefahren
Initiator extended

Klemmleiste
Terminal block

Flanschdose
Flange-socket

Color	Pole	Function
Green	4	Proximity switch: extended
White	3	Proximity switch: retracted
Blue	2	-
Brown	1	+

Assignment 12-pole socket

Steckbuchsenleiste
Female multipoint connector

Initiator eingefahren
Initiator retracted

Initiator ausgefahren
Initiator extended

Klemmleiste
Terminal block

Flanschdose
Flange-socket

Color	Pole	Function
Black	J	Proximity switch: extended
Violet	K	Proximity switch: retracted
Blue	B	-
Brown	A	+
White	C	C1
Red	D	C2
Green	E	C3
Yellow	F	C4
Gray	G	C5
Pink	H	C6

Fig. 5-11 Connection of the integrated proximity switches






Fig. 5-12 Connection diagram for proximity switches

Technical data

Type	NSS-O8-K-29	NSI-Q8-K-44	NSI-Q8-S-59
Switching distance	0.8 mm	1.5 mm	1.5 mm
Circuit type	PNP	PNP	PNP
Switching characteristic	NO	NO	NO
Supply voltage	10-30 V DC	10-30 V DC	10-30 V DC
Current consumption	<10 mA	<10 mA	<10 mA
Switching current	Max. 100 mA	Max. 200 mA	Max. 200 mA
Switching frequency	Max. 1.5 kHz	Max. 3 kHz	Max. 3 kHz
LED	Yes	Yes	Yes
Protected against polarity reversal	Yes	Yes	Yes
Short-circuit proof	Yes	Yes	Yes
Protection	IP 67	IP 67	IP 67
LEN-6, VEN-6	•		
ZWP-6-VEN	(•)	•	•

5.4.3 Repair / Replacement of the hydraulic shock absorber

		WARNING
	<p>Work may only be carried out by specially trained personnel because the device is pressurized.</p> <p>Otherwise light to serious injuries can result.</p> <p>Avoid these dangerous situations!</p>	




Fig. 5-13 Repair / Replacement of the hydraulic shock absorber







Technical data

Type	STD-14-W
Fastening	M14 x 1
Stroke	12 mm
Impact speed (min./max.)	0.4/5.0 m/s
Absorption	30 Nm
Damping work max.	50,000 Nm/h
Material	Steel
Weight	0.065 kg

Linear Unit Type: LEN; VEN; ZWP

5.4.4 Air grommets

In linear units with air grommets, connect the compressed air supply hoses to the connections of the device (identifier A, B, etc.). Connect the mounted peripherals by tapping the air for the peripherals directly at the linear unit in accordance with the corresponding letter for the supply.

		NOTICE
	<p><i>The units LEN and VEN are matched to each other. LEN-6-I-X-H-6-X-P has 6 air grommets. Six matching O-rings are therefore included in the delivery of the LEN-6.</i></p> <p><i>Two connections are tapped for operation of the VEN-6. VEN-6-I-X-H-4-X-P therefore has 4 remaining air grommets.</i></p>	
		NOTICE
	<p><i>The head plate of the LEN-6 is delivered ex works with individually closed air grommets on the front side.</i></p> <p><i>Tapping for integration is effected on the side so that the head plate can be used for loads. If, however, the front-side air grommets are used, their set screws and balls must first be removed. Matching 3.3x2.4 O-rings are enclosed with the delivery for use of the front grommets.</i></p> <p><i>In this case the side outlets must be closed with M5 sealing plugs (not included in the delivery).</i></p>	
		NOTICE
	<p><i>Malfunctions will occur if compressed air openings are not blocked.</i></p> <p><i>Therefore make sure that unused connection possibilities are blocked.</i></p>	







LEN	VEN	ZWP
		
LEN A: extend; B: retract	VEN A: extend; F: retract	ZWP A: extend; B: retract



Fig. 5-14 Air grommets

Operation LEN with VEN+ZWP	Operation LEN only with VEN	VEN in operation with ZWP-6- VEN
a: Extend VEN b: Grommet c: Grommet d: Retract ZWP e: Extend ZWP f : Retract VEN	a: Extend VEN b: Grommet c: Grommet d: Grommet e: Grommet f : Retract VEN	B: Grommet C: Grommet D: Grommet E: Grommet Connection directly at the cylinder block of the ZWP A: Extend B: Retract For this, the set screws and balls must first be removed from the front connections A and B and the side grommets closed with a cover plate (accessory).

		NOTICE
	<p><i>If the linear unit VEN-6 is mounted without the matching unit LEN-6, the air grommets not needed can be closed “en bloc” with a cover plate (accessory).</i></p> <p><i>First place 2 centering rings in the VEN diagonally. Then place 6 O-rings in the cover plate to seal the channels.</i></p> <p><i>Fasten this component to the VEN with a countersunk screw.</i></p> <p><i>For further mounting, position the centering rings directly over the centering rings in the grommet bore of the plate (projection for further mounting).</i></p>	




5.4.5 Electric signal grommets

		NOTICE
	<p><i>The two units are matched to each other. LEN-6-I-X-H-6-6-P has 6 signal grommets. Two connections are tapped for operation of the VEN-6; VEN-6-I-X-H-4-4-P therefore has 4 remaining signal grommets.</i></p>	

Linear Unit Type: LEN; VEN; ZWP

LEN-6-I-X-H-6-6-P

The signal lines can be connected on the side at the front of the LEN-6 via 6 individual three-pole connection sockets (C1-C6) and are collected at the 12-pole socket.




Color	Pole	Function
Black	J	Proximity switch: extended
Violet	K	Proximity switch: retracted
Blue	B	-
Brown	A	+
White	C	C1
Red	D	C2
Green	E	C3
Yellow	F	C4
Gray	G	C5
Pink	H	C6

VEN-6-I-X-H-4-4-P

Connect the signal transmitters via the 3-pole sockets on the multiway connector at the head plate (input). This multiway connector (IP 67) collects the signals and passes them through the unit to the multiway connector on the guide head (long side of the VEN).



From there they can then be forwarded, e.g. to the controller or the LEN-6-I-X-6-6-P.





If the VEN is operated without LEN, signals from the superstructures can be tapped by the front plate multiway connector directly at the 8-pole connector and forwarded to the controller per bus. In this case the multiway connector at the guide head is bypassed. Alternatively, the multi-pole plug connection at the multiway connector of the guide head can be detached and, using a matching mating connector, a bus to the controller installed.

Fig. 5-15 Electric signal grommets

6 Maintenance/Serviceing

		WARNING
	<p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection!</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Make sure there are no residual energies present.</i></p>	

		NOTICE
	<p><i>If you have opted for use with an oil/air mixture, the device should then later not be operated otherwise because the lubricating film could fail.</i></p>	

Shock absorbers

The hydraulic shock absorbers are wearing parts. They should therefore be inspected at regular intervals (about every 2,000,000 strokes). Defective shock absorbers can cause consequential damage. Our STD14 are repairable, and we therefore recommend you arrange the possibility of repair with our customer service.

Serviceing

After a modification/repair, all moving parts and their guides should be smeared with our special grease.

The seals and the grease inside the linear unit can age depending on use; we therefore recommend that you send the device in to us for servicing every 3 years, after 10,000,000 cycles (for ZWP 20,000,000 cycles) or should you notice a fault in the movement.

Only clean the linear unit with soft cloths and agents that do not damage the material.

Contact with aggressive media and grinding dust should be avoided.

6.1 Warranty and guarantee conditions

The statutory warranty period of the manufacturer / distributor is 24 months from the date of delivery.

For spare parts, we guarantee delivery according to chapter (see also DIN EN 82079-1).

We grant a warranty of 24 months (from the date of delivery ex works) on the proviso that the device is treated correctly in 1-shift operation and the application and environmental conditions are complied with. This includes replacement or repair of defective parts of Friedemann Wagner GmbH.

Wearing parts (e.g. shock absorbers) are not covered by the warranty.

During the warranty period repairs may only be carried out or authorized by Friedemann Wagner GmbH.

7 Troubleshooting

Fault	Cause	Correction
Irregular movement	Regulator is turned in too far	Set regulator correctly
	Air ducts are blocked	Clean air ducts with compressed air
No movement	Connected incorrectly	Connect compressed air connections correctly
	Indexing unit controlled incorrectly	Check program and change
	Incorrect switching signal or signal sets in too soon	Set proximity switch correctly, see chapter 5.4.1.
	Faulty switching	Interchange compressed air connections and pressurize with compressed air
	Regulator is turned in too far	Set regulator correctly
Proximity switch emits incorrect signals No switching signal	Proximity switch is set incorrectly	Set proximity switch correctly, see chapter 5.4.1.
	Proximity switch is defective	Replace proximity switch, see chapter 5.4.1.
End-position stop too hard	Shock absorber (G) is set incorrectly	Set shock absorber (G) correctly, see chapter 5.3.5.2.
	Shock absorber (G) is defective	Replace shock absorber (G), see chapter 5.4.3.
End position is not reached No switching signal	Shock absorber turned in too far	Mount shock absorber (G) correctly, see chapter 5.4.3
	Pressure too low	Increase air pressure
	Load too high	Keep to technical data

Table 1 Troubleshooting

You can obtain further help from:

Friedemann Wagner GmbH, D-78559 Gosheim / Germany
 Telephone: +49 (0) 7426 / 94900-0
 Fax: +49 (0) 7426 / 94900-9
 Email: info@wagnerautomation.de

8 Dismantling / Disposal

Dismantling

Dismantling work may only be carried out by skilled personnel. Make sure the shutdown procedure is followed before beginning dismantling work.

Further, the following must be followed where applicable / available:

- Release the energy in the pressure accumulator.
- Make sure there are no residual energies in the system.
- Release all tensioned springs.



Disposal

The device is primarily made of steel and to a certain extent also of aluminum (except for the electrical equipment) and is to be disposed of in accordance with local environmental protection regulations applicable **at the time** of disposal.

Dispose of according to properties, existing laws and regulations as, for example:

- electric and electronic scrap (circuit boards), PC system, keyboard, mouse, monitor (according to WEEE regulations);
- batteries, fluorescent lamps/energy-saving lamps (collection points);
- plastics (housing), rubber;
- metal, steel, copper, aluminum (separated by sorts).

All parts touched by media must be decontaminated before disposal. Hazardous substances are to be removed from the device.


For proper disposal of hazardous substances, observe the material safety data sheets (MSDS) and current applicable disposal regulations.

Oils, solvents, cleaning agents and contaminated cleaning materials (brushes, cloths, etc.) must be disposed of according to local regulations, the applicable disposal codes and the information in the manufacturer's material safety data sheets.

9 Spare part lists and accessories

9.1 Spare part lists


LEN-6



Pos	name	Item#	Pos	name	Item#	Pos	name	Item#
1	left bracket screw M4x8	6002.002	22	rod	1151.000.102	43	rod	1151.000.102
2	rod	6002.002	23	rod	1151.000.102	44	rod	1151.000.102
3	rod	6002.002	24	rod	1151.000.102	45	rod	1151.000.102
4	rod	6002.002	25	rod	1151.000.102	46	rod	1151.000.102
5	rod	6002.002	26	rod	1151.000.102	47	rod	1151.000.102
6	rod	6002.002	27	rod	1151.000.102	48	rod	1151.000.102
7	rod	6002.002	28	rod	1151.000.102	49	rod	1151.000.102
8	rod	6002.002	29	rod	1151.000.102	50	rod	1151.000.102
9	rod	6002.002	30	rod	1151.000.102	51	rod	1151.000.102
10	rod	6002.002	31	rod	1151.000.102	52	rod	1151.000.102
11	rod	6002.002	32	rod	1151.000.102	53	rod	1151.000.102
12	rod	6002.002	33	rod	1151.000.102	54	rod	1151.000.102
13	rod	6002.002	34	rod	1151.000.102	55	rod	1151.000.102
14	rod	6002.002	35	rod	1151.000.102	56	rod	1151.000.102
15	rod	6002.002	36	rod	1151.000.102	57	rod	1151.000.102
16	rod	6002.002	37	rod	1151.000.102	58	rod	1151.000.102
17	rod	6002.002	38	rod	1151.000.102	59	rod	1151.000.102
18	rod	6002.002	39	rod	1151.000.102	60	rod	1151.000.102
19	rod	6002.002	40	rod	1151.000.102	61	rod	1151.000.102
20	rod	6002.002	41	rod	1151.000.102			
21	rod	6002.002	42	rod	1151.000.102			
22	rod	6002.002	43	rod	1151.000.102			
23	rod	6002.002	44	rod	1151.000.102			
24	rod	6002.002	45	rod	1151.000.102			
25	rod	6002.002	46	rod	1151.000.102			
26	rod	6002.002	47	rod	1151.000.102			
27	rod	6002.002	48	rod	1151.000.102			
28	rod	6002.002	49	rod	1151.000.102			
29	rod	6002.002	50	rod	1151.000.102			
30	rod	6002.002	51	rod	1151.000.102			
31	rod	6002.002	52	rod	1151.000.102			
32	rod	6002.002	53	rod	1151.000.102			
33	rod	6002.002	54	rod	1151.000.102			
34	rod	6002.002	55	rod	1151.000.102			
35	rod	6002.002	56	rod	1151.000.102			
36	rod	6002.002	57	rod	1151.000.102			
37	rod	6002.002	58	rod	1151.000.102			
38	rod	6002.002	59	rod	1151.000.102			
39	rod	6002.002	60	rod	1151.000.102			
40	rod	6002.002	61	rod	1151.000.102			
41	rod	6002.002						
42	rod	6002.002						
43	rod	6002.002						
44	rod	6002.002						
45	rod	6002.002						
46	rod	6002.002						
47	rod	6002.002						
48	rod	6002.002						
49	rod	6002.002						
50	rod	6002.002						
51	rod	6002.002						
52	rod	6002.002						
53	rod	6002.002						
54	rod	6002.002						
55	rod	6002.002						
56	rod	6002.002						
57	rod	6002.002						
58	rod	6002.002						
59	rod	6002.002						
60	rod	6002.002						
61	rod	6002.002						



VEN-6



VEN-6-L...-H-4-4-P

Pos.	name	Item#	pcs	Pos.	name	Item#	pcs	Pos.	name	Item#	pcs	Pos.	name	Item#	pcs
1	nut M8x1	6025.011	2	13	nut M6	6025.003	1	25	final plate	1502.000.105	1	37	helix cable	6509.006	1
2	stop screw	1500.000.109.02	1	14	washer M5	6020.008	1	26	sliding tube guide	*1502.500.000	4	38	sliding tube	*1500.000.103	4
3	countersunk screw	1500.000.102	1	15	piston complete 20x5	6211.016	1	27	O-ring 6x2.2	6210.017	3	39	ball lining 16x24x30	6250.004	4
4	O-ring 6.5x1.6	6210.067	1	16	flat headed screw M4x6	6002.005	4	28	O-ring 10x1	6210.049	4	40	guide rod	*1502.503.101	1
5	air coupler	1500.503.101	1	17	guide shaft	*1500.000.107	1	29	guide header	1502.600.101	1	41	piston rod	*1500.000.106	1
6	O-ring 17.3x2.4	6210.011	2	18	shaft sealing 8x15	6216.001	1	30	cylinder screw M3x18	8003.048	4	42	countersunk screw M4x6	6007.002	1
7	cylinder cap	1500.506.101	1	19	stop screw	1500.000.106.01	1	31	angled plug socket	8508.013	2	43	countersunk unit	1502.000.103	1
8	cylinder tube	*1500.502.101	1	20	screw-in unit	1500.505.101	1	32	terminal	STL-E-E43-A8	2	44	O-ring 3.3x2.4	*6210.001	4
9	air pipe	*1502.000.101	1	21	grub screw M6x8	6001.001	1	33	plain bearing 4x5.5x4	6200.015	4	45	countersunk screw M4x25	6000.016	2
10	O-ring 22x1.5	6210.027	2	22	top plate	1502.000.104	1	34	combined element 4x8.2	6216.009	4				
11	shock absorber	STD-14-W	2	23	countersunk screw M6x16	6000.005	1	35	strain relief	1151.000.102	2				
12	cover	*1502.000.106	1	24	countersunk screw M8x16	6000.001	3	36	cylinder screw M3x8	8003.027	2				




Fig. 9-1 Spare part list

9.2 Accessories

The following accessories are available from us for the linear units.

	LEN-6	VEN-6	ZWP
Centering rings	ZR-6	ZR-6 ZR-9	ZR-6
Proximity switches	NSS-O8-K-29	NSS-O8-K-29	NSI-Q8-K-44
5 m connection cable, 4-wire	•		
5 m connection cable, 10-wire	• (LEN-6-I)		
5 m connection cable, 8-wire		•	
Shock absorbers	STD-14-W	STD-14-W	STD-14-W
Fastening screws M6x30	•	•	
Connector, 3-pole	•	•	
Stand	•		
Sheet metal cover	•	•	
ZWP-6		•	
Multiway connector STL-8-E43-A8		•	
Cover plate VSP-6-VEN With fastening and sealing material 8 x ZR-6 centering rings 6 x O-rings 3.3 x 2.4 Countersunk screw		•	•
Accessories LEN/VEN-6 6 x connectors 3 x cylinder head screws M6x30 1 x 5 m cable	•		
4 x ZR-6 centering rings 6 x O-rings 3.3 x 2.4	•	•	
3 x cylinder head screws M6x70			•