




**FRIEDEMANN
WAGNER**
Handhabungstechnik

Installation and Operating Instructions

Linear Unit

Type: LSM; LSK





Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Internet: <http://www.wagnerautomation.de>
Email: info@wagnerautomation.de

Edition 04/2017

Translation of Original Installation and Operating Instructions

| | | |
|---|---|---------------|
|  |  | NOTICE |
| | <p><i>Important! – Read carefully before use – Keep for future reference!</i></p> <p><i>The installation and operating instructions are an integral part of the device and must be available to the operating and maintenance personnel at all times. The safety information contained in them must be heeded accordingly.</i></p> <p><i>If the device is resold, these installation and operating instructions must always be delivered with it as well. The latest version is to be found on the Internet at the manufacturer's website: http://www.wagnerautomation.de</i></p> | |

Warranty and guarantee conditions:

See chapter 6.1, Warranty and guarantee conditions.

The **warning and safety symbols** are explained in chapters 3.1 and 3.1.1.

Translation

If the device is sold to a country in the EEA, these installation and operating instructions must be translated into the language of the country in which the device is to be used. Should the translated text be unclear, the original installation and operating instructions (German) must be consulted or the manufacturer contacted for clarification.

Copyright

No part of this publication may be reproduced, transmitted, sold or disclosed without prior permission. Damages will be claimed for violations.

All rights reserved.

Document name:

[Dss737 BA_722_Lineareinheit-LSM_LSK-
04_08_2016_Druckversion gez_7_2016.doc](#)

1 Contents

1.1 Table of contents

| | | |
|----------|---|-----------|
| 1 | Contents | 3 |
| 1.1 | Table of contents | 3 |
| 1.2 | Table of figures | 4 |
| 1.3 | List of tables | 4 |
| 1.4 | Declaration of incorporation | 5 |
| 2 | Overview and intended use | 6 |
| 2.1 | Overview of the device | 6 |
| 2.2 | Intended use | 7 |
| 2.2.1 | Product identification | 8 |
| 2.2.2 | Incorporation information (for the partly completed machinery) for the constructor of the final machinery | 9 |
| 2.3 | Technical data | 10 |
| 2.3.1 | Dimensions and weight | 10 |
| 2.3.2 | Environmental conditions | 11 |
| 2.3.3 | Characteristics and allowable loads | 12 |
| 2.3.4 | General data | 15 |
| 3 | Safety | 16 |
| 3.1 | Notes and explanations | 16 |
| 3.1.1 | Explanation of safety symbols used | 17 |
| 3.2 | Safety precautions (to be carried out by the operator) | 18 |
| 3.3 | Safety inspections and tests | 18 |
| 4 | General warnings | 19 |
| 4.1 | Dangers | 19 |
| 4.2 | Spare and wearing parts | 19 |
| 5 | Installation | 21 |
| 5.1 | Scope of delivery | 21 |
| 5.2 | Transport and packaging | 22 |
| 5.2.1 | Delivery (also of spare and replacement parts) | 22 |
| 5.2.2 | Temporary storage/Storage conditions | 23 |
| 5.3 | Mounting | 24 |
| 5.3.1 | Mounting of the linear unit | 24 |
| 5.3.2 | Mounting of superstructures | 25 |
| 5.3.3 | Connection examples | 26 |
| 5.3.3.1 | Example of standard pneumatic connection | 27 |
| 5.3.3.2 | Example of pneumatic connection with EMERGENCY STOP circuit | 28 |
| 5.3.4 | Adjustment possibilities for the linear unit | 29 |
| 5.3.4.1 | Set speed | 29 |
| 5.3.4.2 | Set shock absorber | 30 |
| 5.4 | Startup | 32 |
| 5.4.1 | Mounting of proximity switches (accessories) | 33 |
| 5.4.2 | Repair / Replacement of the hydraulic shock absorber | 35 |

Linear Unit Type: LSM; LSK

| | | |
|----------|---|-----------|
| 6 | Maintenance/Serviceing | 37 |
| 6.1 | Warranty and guarantee conditions | 38 |
| 7 | Troubleshooting | 39 |
| 8 | Dismantling / Disposal | 40 |
| 9 | Spare part lists and accessories | 41 |
| 9.1 | Spare part lists | 41 |
| 9.2 | Accessories | 43 |

1.2 Table of figures

| | | |
|----------|---|----|
| Fig. 2-1 | Diagram of the parts of the linear unit | 6 |
| Fig. 2-2 | Characteristics and loads | 14 |
| Fig. 5-1 | Scope of delivery of the device | 21 |
| Fig. 5-2 | Mounting of superstructures using two linear units of the type LSM as example | 26 |
| Fig. 5-3 | Standard circuit | 27 |
| Fig. 5-4 | Emergency stop circuit | 28 |
| Fig. 5-5 | Adjustment possibilities for the linear unit | 29 |
| Fig. 5-6 | Set shock absorber for STD-14 | 31 |
| Fig. 5-7 | Connection diagram for proximity switches | 34 |
| Fig. 5-8 | Repair / Replacement of the hydraulic shock absorber | 35 |
| Fig. 9-1 | Spare part list | 42 |

1.3 List of tables

| | | |
|---------|-----------------|----|
| Table 1 | Troubleshooting | 39 |
|---------|-----------------|----|

1.4 Declaration of incorporation

Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Declaration of incorporation

pursuant to the

- **EC Machinery Directive 2006/42/EC**
- **EC EMC Directive 2014/30/EU**

We hereby declare that the design of the

Designation: Linear Unit

Type: LSM-X-SM-X-X-X-X-P / LSK-X-X-X-X-X-P

as delivered complies with the above directives.

Harmonized DIN EN standards applied pursuant to the Official Journals for the directives:

| Directive / Standard | Title |
|-----------------------------|--|
| DIN EN ISO 82079-1 :2012 | Preparation of instructions for use – Structuring, content and presentation – Part 1: General principles and detailed requirements |
| 2006/42/EC | EC Directive: Machinery <i>effective from 2009-12-29</i> |
| DIN EN ISO 12100 :2010 | Safety of machinery – General principles for design – Risk assessment and risk reduction |

- This declaration only applies to the linear unit in the state in which it was placed on the market.
- The essential health and safety requirements according to Annex I of the Machinery Directive were applied and are fulfilled.
- The following chapters in Annex I of the Machinery Directive 2006/42/EC were considered in the risk assessment:
1.1.2, 1.1.3, 1.1.5, 1.2.6, 1.3.1, 1.3.2, 1.3.3, 1.3.4, 1.3.6, 1.3.7, 1.3.8.2, 1.3.9,
1.4.1, 1.4.2.1, 1.5.3, 1.5.4, 1.5.9, 1.5.11, 1.5.15, 1.6.1, 1.6.4, 1.7.1, 1.7.2, 1.7.3, 1.7.4.
- The special technical file according to Annex VII B was compiled and will be presented to the competent national authorities in electronic form on demand.
- **The linear unit may not be put into service until the final machinery into which it is incorporated has been declared in conformity with the provisions of the directives.**
- The person authorized to compile the technical documentation is:
Name: Mr. Andreas Wagner
Address: Robert-Bosch-Straße 5, D-78559 Gosheim / Germany

Gosheim, April 2017

Authorized Signature
(A. Wagner, Managing Director)

2 Overview and intended use

2.1 Overview of the device






Fig. 2-1 Diagram of the parts of the linear unit

| The LSM / LSK linear unit consists of the following main components: | |
|---|--|
| (A) Head plate (B) Bores for fastening with centering rings (C) Stop screws, hardened (D) Stop plate, hardened (E) Fastening screws to clamp the stop screws | (F) Mount for proximity switch (G) Hydraulic shock absorber (I) Centering rings |

2.2 Intended use



The linear units were developed to move components or superstructures a defined distance horizontally or vertically. They are suitable for positioning in assembly work or processing of components.

This device was developed, designed and built exclusively for industrial and light-industrial use. Private use is prohibited.

| | |
|---|---|
|  |  DANGER |
| | <p><i>This device is intended solely for the purpose described above. Any other use or modification of the device without the written consent of the manufacturer is deemed improper.</i></p> <p><i>Modification without written agreement will lead to serious to deadly injuries.</i></p> <p><i>The manufacturer accepts no liability for resultant damage. The risk is borne solely by the operator. The device may only be put into operation when it has been ensured that all safety devices have been installed and are fully functional.</i></p> |

Proper use of the device in accordance with its intended purpose includes compliance with the manufacturer's instruction handbooks and operating manuals and performance of all specified maintenance and service work.

Foreseeable misuse:

| | |
|---|--|
|  |  NOTICE |
| | <p><i>Products that could form explosive dust/air or gas/air mixtures may not be processed in critical concentrations (above LEL)!</i></p> <p><i>The device does not fulfil any EX requirements and may therefore also not be installed and operated in ATEX zones!</i></p> <p><small>*) LEL = Lower Explosive Limit</small></p> |

The device is not suitable for use in machining operations, especially of aluminum, titanium and magnesium, as, depending on product compositions, particle sizes, chip sizes and distribution of quantities, potentially explosive atmospheres can result. The final decision on use lies in the end user's judgment.

Linear Unit Type: LSM; LSK

2.2.1 Product identification

The type key is laser-engraved on the connection side of the linear unit. The following table explains the type key:

| Module | Design size | Version | Stroke | Shock absorber | Energy feedthrough | Drive |
|------------------------------|-------------|--|---|--|---|------------------------|
| LSM | 3 | SM | 20 35 50 | K H | 0--0 | -P |
| LSM | 4 | SM | 35 65 | K H | 0--0 | -P |
| LSK | 4 | SK HK | 20 30 45 60 75 90 | K H | 0--0 | -P |
| LSK | 6 | SK | 30 50 75 100 125 150 175 200 | K H | 0--0 | -P |
| LS linear slide | | SM slide mini SK slide + cross roller guide stop at side K slide + cross roller guide stop at face | | K unavailable H hydraulic | 0- pneumatic -0 electric | -P pneumatic |

2.2.2 Incorporation information (for the partly completed machinery) for the constructor of the final machinery

- Control is effected via a 4/2 or 5/2 directional-control valve (not included in the delivery).
- The threaded bores and centering rings enable easy mounting.
- The speed can be adjusted freely with an external exhaust regulator (not included in the delivery).

After considering the above points, the integrator of the final machinery can put this device into service as a safe device.

He must supply overall instructions for use and a declaration of conformity for the complete machinery and affix a type plate with CE marking to the machinery. The responsibility for the risk assessment for the complete machinery lies internally with the integrator.

Linear Unit Type: LSM; LSK

2.3 Technical data

2.3.1 Dimensions and weight

| | LSM-3-SM | LSM-4-SM | LSK-4-SK | LSK-4-HK | LSK-6-SK |
|-------------------------------|--|------------|-------------------------------|----------------------|--------------------------------------|
| Guide | Recirculating ball bearing guide with two carriages | | Cross roller guide | | |
| Design | For smallest installation spaces | | For small installation spaces | | |
| Stop | Side | Side | Side | Face | Side |
| Stroke lengths [mm] | 20/35/50 | 35/65 | 20/30/45 60/75/90 | 20/30/45 60/75/90 | 30/50/75/ 100/125/ 150/175/200 |
| Adjustment range [mm] | 15 | 14 | 14 | 14 | 23 |
| Type | Both sides | Both sides | Both sides | Both sides | Both sides |
| Repeatability [mm] | ±0.01 | ±0.01 | ±0.01 | ±0.01 | ±0.01 |
| Push force at 6 bar [N] | 11 | 18 | 45 | 45 | 76 |
| Retraction force at 6 bar [N] | 7 | 13 | 33 | 33 | 66 |
| Cylinder Ø [mm] | 6 | 8 | 12 | 12 | 16 |
| Drive | Compressed air (4-8 bar), constant, filtered (10 µm) and dry | | | | |
| Connection | M3 | | M5 | | |
| Control | 4/2; 5/2 directional-control valve, bistable | | | | |
| Housing material | High strength aluminum, anodized | | | | |
| Stop system material | Hardened steel | | | | |
| Stop screw material | Hardened steel | | | | |








| Module | LSM-3-SM | | | LSM-4-SM | | LSK-4-SK LSK-4-HK | | | | | |
|-------------------------------------|----------|------|------|----------|-----|----------------------|-----|------|------|------|------|
| Stroke length [mm] | 20 | 35 | 50 | 35 | 65 | 20 | 30 | 45 | 60 | 75 | 90 |
| Weight [kg] | 0.06 | 0.08 | 1 | 0.2 | 0.3 | 0.5 | 0.5 | 0.62 | 0.74 | 0.86 | 0.98 |
| Air consumption double stroke [cm³] | 1.13 | 2 | 2.83 | 3.5 | 6.5 | 5.7 | 6.8 | 10.2 | 13.5 | 17.0 | 20.4 |
| Max. payload [kg] | 0.5 | 0.5 | 0.5 | 1.2 | 1.2 | 3 | 3 | 3 | 3 | 3 | 3 |








| Module | LSK-6-SK | | | | | | | |
|-------------------------------------|----------|------|------|------|------|------|------|------|
| Stroke length [mm] | 30 | 50 | 75 | 100 | 125 | 150 | 175 | 200 |
| Weight [kg] | 1.07 | 1.07 | 1.47 | 1.47 | 1.83 | 1.83 | 2.2 | 2.2 |
| Air consumption double stroke [cm³] | 11.2 | 18.7 | 28 | 37.4 | 46.8 | 56.1 | 65.5 | 74.8 |
| Max. payload [kg] | 22 | 22 | 18 | 18 | 14 | 14 | 10 | 10 |

2.3.2 Environmental conditions

- Operation only in closed rooms and low-vibration environments (no potentially explosive or condensing atmospheres).
- No operation in environments with spray water, vapors, process dusts or abrasion dusts.
- Linear units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.
- The linear units are only suitable for use in environments with spray water to a limited extent. It might be necessary to protect them against ingressing spray water with a suitable cover.

2.3.3 Characteristics and allowable loads

| LSM-3-SM | | | | | | | | | | | | | | | |
|---|-------------------------------------|--------------------------------|--|--|------------------------------------|-----------|-----------|-----------------|--------------|------------------|------------------------|-----------------------|------------------|-------------------------------------|--------------------------------|
|  | | | Zulässige Belastungen statisch/dynamisch Allowable loads static/dynamic | | | | | | | | | | | | |
| | | | M01 [Nm] | M02 [Nm] | M03 [Nm] | A [mm] | B [mm] | C [mm] | | | | | | | |
|  $M01=(A+L1) \times F01$  $M01=(C+L1) \times F01$ | | |  $M02=(A+L2) \times F02$  $M02=(B+L2) \times F02$ |  $M03=(B+L3) \times F03$  $M03=(C+L3) \times F03$ | Minischlitten LSM-3-SM-20/35/50 | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| <div>Lebensdauerberechnung mit Momenten Lifetime calculation with moments</div> <div>$L=\left(\frac{M_{zul}}{M_{eff}}\right)^3 \times 10^5$</div> <table><tr><td>L</td><td>Lebensdauer [m]</td><td>lifetime [m]</td></tr><tr><td>M_{zul}</td><td>zulässiges Moment [Nm]</td><td>allowable moment [Nm]</td></tr><tr><td>M_{eff}</td><td>effektives (benötigtes) Moment [Nm]</td><td>effective (needed) moment [Nm]</td></tr></table> <div>Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein: In combined loads situations the next equation must be met:</div> <div>$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$</div> | | | | | | | L | Lebensdauer [m] | lifetime [m] | M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] | M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] |
| L | Lebensdauer [m] | lifetime [m] | | | | | | | | | | | | | |
| M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] | | | | | | | | | | | | | |
| M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] | | | | | | | | | | | | | |

| LSM-4-SM | | | | | | | | | | | | | | | |
|---|-------------------------------------|--------------------------------|--|--|------------------------------|-----------|-----------|-----------------|--------------|------------------|------------------------|-----------------------|------------------|-------------------------------------|--------------------------------|
|  | | | Zulässige Belastungen statisch/dynamisch Allowable loads static/dynamic | | | | | | | | | | | | |
| | | | M01 [Nm] | M02 [Nm] | M03 [Nm] | A [mm] | B [mm] | C [mm] | | | | | | | |
|  $M01=(A+L1) \times F01$  $M01=(C+L1) \times F01$ | | |  $M02=(A+L2) \times F02$  $M02=(B+L2) \times F02$ |  $M03=(B+L3) \times F03$  $M03=(C+L3) \times F03$ | Minischlitten LSM-4-SM-35/65 | | | | | | | | | | |
| | | | | | | | | | | | | | | | |
| <div>Lebensdauerberechnung mit Momenten Lifetime calculation with moments</div> <div>$L=\left(\frac{M_{zul}}{M_{eff}}\right)^3 \times 10^5$</div> <table><tr><td>L</td><td>Lebensdauer [m]</td><td>lifetime [m]</td></tr><tr><td>M_{zul}</td><td>zulässiges Moment [Nm]</td><td>allowable moment [Nm]</td></tr><tr><td>M_{eff}</td><td>effektives (benötigtes) Moment [Nm]</td><td>effective (needed) moment [Nm]</td></tr></table> <div>Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein: In combined loads situations the next equation must be met:</div> <div>$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$</div> | | | | | | | L | Lebensdauer [m] | lifetime [m] | M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] | M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] |
| L | Lebensdauer [m] | lifetime [m] | | | | | | | | | | | | | |
| M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] | | | | | | | | | | | | | |
| M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] | | | | | | | | | | | | | |

LSK-4-SK

$$M01 = (A + L1) \times F01$$

$$M02 = (A + L2) \times F02$$

$$M03 = (B + L3) \times F03$$

$$M01 = (C + L1) \times F01$$

$$M02 = (B + L2) \times F02$$

$$M03 = (C + L3) \times F03$$

Linearschlitten

Zulässige Belastungen
statisch/dynamisch
Allowable loads
static/dynamic

| | M01 (Nm) | M02 (Nm) | M03 (Nm) | A (mm) | B (mm) | C (mm) |
|-------------|-------------|-------------|-------------|-----------------------------|-----------|-----------|
| LSK-4-SK-20 | 12 | 12 | 17 | $29 + \frac{\text{Hub}}{2}$ | 9 | 13 |
| LSK-4-SK-30 | 12 | 12 | 17 | $29 + \frac{\text{Hub}}{2}$ | 9 | 13 |
| LSK-4-SK-45 | 15 | 15 | 20 | $36 + \frac{\text{Hub}}{2}$ | 9 | 13 |
| LSK-4-SK-60 | 18 | 18 | 23 | $44 + \frac{\text{Hub}}{2}$ | 9 | 13 |
| LSK-4-SK-75 | 21 | 21 | 26 | $51 + \frac{\text{Hub}}{2}$ | 9 | 13 |
| LSK-4-SK-90 | 25 | 25 | 29 | $59 + \frac{\text{Hub}}{2}$ | 9 | 13 |

Lebensdauerberechnung mit Momenten
Lifetime calculation with moments

$$L = \left(\frac{M_{zul}}{M_{eff}} \right)^3 \times 10^5$$

| | | |
|------------------|-------------------------------------|--------------------------------|
| L | Lebensdauer [m] | lifetime [m] |
| M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] |
| M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] |

Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein:
In combined loads situations the next equation must be met:

$$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$$

LSK-6-SK

$$M01 = (A + L1) \times F01$$

$$M02 = (A + L2) \times F02$$

$$M03 = (B + L3) \times F03$$

$$M01 = (C + L1) \times F01$$

$$M02 = (B + L2) \times F02$$

$$M03 = (C + L3) \times F03$$

Linearschlitten LSK-6-SK

Zulässige Belastungen
statisch/dynamisch

Allowable loads
static/dynamic

| | M01 [Nm] | M02 [Nm] | M03 [Nm] | A [mm] | B [mm] | C [mm] |
|----------|-------------|-------------|-------------|------------------------------|-----------|-----------|
| -30/50 | 33.2 | 33.2 | 44.6 | $45 + \frac{\text{Hub}}{2}$ | 14 | 16 |
| -75/100 | 38.7 | 38.7 | 59.5 | $70 + \frac{\text{Hub}}{2}$ | 14 | 16 |
| -125/150 | 44.2 | 44.2 | 59.5 | $95 + \frac{\text{Hub}}{2}$ | 14 | 16 |
| -175/200 | 49.7 | 49.7 | 74.4 | $120 + \frac{\text{Hub}}{2}$ | 14 | 16 |

Lebensdauerberechnung mit Momenten
Lifetime calculation with moments








$$L = \left(\frac{M_{zul}}{M_{eff}} \right)^3 \times 10^5$$

| L | Lebensdauer [m] | lifetime [m] |
|------------------|-------------------------------------|--------------------------------|
| M _{zul} | zulässiges Moment [Nm] | allowable moment [Nm] |
| M _{eff} | effektives (benötigtes) Moment [Nm] | effective (needed) moment [Nm] |

Bei kombinierten Belastungen muss folgende Gleichung erfüllt sein:
In combined loads situations the next equation must be met:

$$\frac{M01_{eff}}{M01_{zul}} + \frac{M02_{eff}}{M02_{zul}} + \frac{M03_{eff}}{M03_{zul}} \leq 1$$

Deflection under load LSK-4-SK



Deflection under load LSK-6-SK













Fig. 2-2 Characteristics and loads

2.3.4 General data

Operating temperature range:

Temperature range device:

+ 5° ... + 65° C

Relative air humidity:

max. 70 %, non-condensing

Storage conditions:

Minimum temperature:

- 10° C

Maximum temperature:











+ 50° C

Relative air humidity:










max. 70 %, non-condensing

3 Safety

3.1 Notes and explanations

| | |
|---|---|
|  | <div data-bbox="384 445 480 517"></div> <div data-bbox="480 445 1442 517">DANGER</div> <p><i>“DANGER” warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise serious injuries or death will result.</i></p> |
|  | <div data-bbox="384 674 480 745"></div> <div data-bbox="480 674 1442 745">WARNING</div> <p><i>“WARNING” warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise serious injuries or death can result.</i></p> |
|  | <div data-bbox="384 902 480 974"></div> <div data-bbox="480 902 1442 974">CAUTION</div> <p><i>“CAUTION” in combination with the warning symbol warns of dangerous situations. Avoid these dangerous situations!</i></p> <p><i>Otherwise minor or light injuries could result.</i></p> |
|  | <div data-bbox="384 1162 480 1234"></div> <div data-bbox="480 1162 1442 1234">NOTICE</div> <p><i>“NOTICE” gives recommendations on how to proceed. Ignoring these recommendations will not lead to personal injuries.</i></p> <p><i>Follow the recommendations to avoid damage to the unit and problems in general!</i></p> |
|  | <div data-bbox="384 1453 480 1525"></div> <div data-bbox="480 1453 1442 1525">NOTICE</div> <p><i>References to installation and operating instructions / documentation are marked with a book symbol (see external documentation).</i></p> <p><i>Follow the recommendations to avoid damage to the unit and problems in general!</i></p> |

3.1.1 Explanation of safety symbols used

| | | |
|---|---|----------------|
|  |  | DANGER |
| | <p>Crushing hazards, dangers of injuries to the hands (closing movements of mechanical parts).</p> <p>Ignoring this warning will result in serious injuries or death. Do not carry out any manual work on such parts during movements.</p> | |
|  |  | WARNING |
| | <p>Mandatory: Safety boots must be worn.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers to the lower limbs.</p> | |
|  |  | WARNING |
| | <p>Mandatory: Protective gloves must be worn.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers to the hands.</p> | |
|  |  | WARNING |
| | <p>Mandatory: Hands must be washed.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers due to deficient hygiene.</p> | |
|  |  | NOTICE |
| | <p>The environment sign marks actions to protect the environment (warning of environmental pollution, in the chapter Disposal).</p> <p>Damage to the environment will result if ignored. Improper disposal can result in serious damage to the environment.</p> | |

3.2 Safety precautions (to be carried out by the operator)

- ▶ The linear units may only be installed, serviced and modified by qualified skilled personnel. This personnel must have read and understood the operating instructions.
- ▶ The energy and compressed air supply must be disconnected from the linear unit before any service, maintenance or modification work. Make sure there are no residual energies present.
- ▶ Only use the linear units if they are in perfect technical condition and do not carry out any unauthorized modifications.
- ▶ The linear units can be heavy. Secure them so that they cannot fall down.
- ▶ In the event of an emergency, malfunction or other irregularity, switch off the linear unit, disconnect it from the energy and compressed air supply and lock against reconnection.
- ▶ Carry out a visual inspection of the compressed air lines regularly. Operation with damaged compressed air lines is prohibited.
- ▶ Make sure that the technical specifications and environmental conditions specified in the product documentation are adhered to.
- ▶ The linear unit may only be operated in accordance with its intended use.
- ▶ Take note of the valid regulations on accident prevention and environmental protection.
- ▶ Implement the safeguards required by EC directives.
- ▶ Pressurize your complete equipment with compressed air slowly to avoid uncontrolled movements.
- ▶ Only put your equipment into service if you are sure that no personnel or foreign objects can be caught by the moving parts.

3.3 Safety inspections and tests



Factory inspections and tests by the manufacturer.

1. Risk assessment according to Machinery Directive 2006/42/EC (to Annex I) and to DIN EN ISO 12100:2010.

4 General warnings

4.1 Dangers

The safety systems and safety instructions described in these installation and operating instructions are to be heeded accordingly.



| | | |
|---|--|---------------|
|  |  | DANGER |
| | <p><i>Pay attention to the possible danger of injuries to the hands and/or body when carrying out adjustment, maintenance and repair work!</i></p> <p>Otherwise serious injuries or death will result.</p> <p><i>The machine builder must implement safety equipment to ensure safe operation.</i></p> | |



4.2 Spare and wearing parts

Spare parts and accessories that have not been supplied by us have also not been tested and approved by us. The fitting and/or use of such products could therefore negatively affect the design characteristics of your device.

We accept no liability whatsoever for damage arising from the use of non-original parts and accessories.

Standard parts can be bought through the specialized trade.

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p>Part lists and technical data sheets are to be found in the technical reference documents.</p> <p>Otherwise the unit will be damaged.</p> <p><i>Damage can arise if the technical reference documents are ignored.</i></p> | |

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p>Lists of spare parts and wearing parts are to be found in the technical reference documents.</p> <p>Otherwise the unit will be damaged.</p> <p><i>Damage can arise if the technical reference documents are ignored.</i></p> | |

Service

When necessary, these parts can be obtained from:

Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany
Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Email: info@wagnerautomation.de

5 Installation

5.1 Scope of delivery



Fig. 5-1 Scope of delivery of the device

The scope of delivery comprises:

- 1 Linear unit
- 2 These installation and operating instructions with declaration of incorporation
- 3 Centering ring
- 4 Cardboard packaging

5.2 Transport and packaging

The customer is sent a specification of the scope of delivery before shipment begins. It contains details on:

- date of delivery,
- number and type of transport units.

The devices are carefully inspected and packed before shipment, but it is nevertheless still possible that they might become damaged during transit.

5.2.1 Delivery (also of spare and replacement parts)

Receiving inspection:

- Check the shipment against the delivery note to ensure that it is complete!

If the packaging is damaged

- Check the shipment itself for damage (visual inspection)!

Complaints

If the shipment was damaged during transit:

- Immediately contact the last carrier!
- Keep the packaging material (for possible inspection by the carrier or for return shipment).



Packaging for return shipment

Use the original packaging material as far as possible.

5.2.2 Temporary storage/Storage conditions

The freight packaging of the device and spare and replacement parts is designed for a storage period of 3 months from delivery.



After dismantling of the device, it must be stored properly to enable reuse.

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>Temporary storage: Store with desiccant in a dry factory hall.</i></p> <p><i>Otherwise the unit will be damaged.</i></p> <p><i>Moisture could penetrate into the device and cause major damage.</i></p> | |



Storage conditions

- No direct sunlight.
- No exposure to direct rain, condensation, water.



5.3 Mounting



| | | |
|---|---|----------------|
|  |  | WARNING |
| | <p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |

5.3.1 Mounting of the linear unit

| | | |
|--|---|----------------|
|  |  | WARNING |
| | <p><i>When mounting in a vertical position, the slide must always be moved to bottommost position before mounting.</i></p> <p><i>Otherwise light to serious injuries can result from sudden moving masses.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |



- ▶ Place at least 2 diagonally offset centering rings (I) (are included in the delivery) in the holes (B) provided.
- ▶ Screw the linear unit tight with screws.
- ▶ Linear units in the LSK series can also be mounted through the housing using through holes and DIN 912 / M4 cylinder head screws (exception: LSK-4-X-30). The guide head must then be moved to reach the holes.

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>If the linear unit is mounted vertically, it must be checked whether the push force and end-position damping suffice for the respective application in question.</i></p> | |

| | | |
|---|---|---------------|
|  |  | NOTICE |
| | <p><i>If a centering ring (I) is stuck in a hole, you can remove it from the hole easily from size ZR-4 with a threaded screw. The centering rings have an internal thread specifically for this purpose. Simply screw a suitable screw into the thread of the centering ring and pull the screw plus centering ring out of the hole.</i></p> | |

| Centering ring | Internal thread |
|----------------|-----------------|
| ZR-3 | - |
| ZR-4 | M5 |
| ZR-6 | M8 |
| ZR-9 | M10 |

5.3.2 Mounting of superstructures

| | | |
|---|---|----------------|
|  |  | WARNING |
| | <p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |

- Fasten the superstructures with screws in the threaded holes (B) with the centering rings provided.




Fig. 5-2 Mounting of superstructures using two linear units of the type LSM as example

5.3.3 Connection examples

| | | |
|--|--|----------------|
| | | WARNING |
| | <p>Disconnect the linear unit from the compressed air supply and lock against reconnection.</p> <p>Otherwise light to serious injuries can result.</p> <p>Avoid these dangerous situations!</p> | |

| | | |
|--|--|---------------|
| | | NOTICE |
| | <p>The following figures show connection examples and illustrate how the linear unit can be connected.</p> | |

| | | |
|--|---|---------------|
| | | NOTICE |
| | <p>A function check must be carried out with compressed air after connection.</p> | |

Linear Unit Type: LSM; LSK

5.3.3.1 Example of standard pneumatic connection








Fig. 5-3 Standard circuit

- A. Compressed air connection A (extend/retract, cf. table)
- B. Compressed air connection B (extend/retract, cf. table)
- 1. 5/2 control valve, bistable

| Connection | LSM-3-SM | LSM-4-SM | LSK-4-SK | LSK-4-HK | LSK-6-SK |
|---|----------|----------|----------|----------|----------|
| View side A | Extend | Extend | Extend | Extend | Extend |
| View side B (near head plate) | Retract | Retract | Retract | Retract | Retract |
| View from below A | | Extend | | | Extend |
| View from below B (near head plate) | | Retract | | | Retract |
| View face end, housing bottom Connection left | | | | Retract | Extend |
| View face end, housing bottom Connection right | | | | Extend | Retract |

5.3.3.2 Example of pneumatic connection with EMERGENCY STOP circuit

| | | |
|---|--|----------------|
|  |  | WARNING |
| | <p><i>In the event of a sudden loss of pressure the payload can drop uncontrolled into one end position. To prevent this, piloted non-return valves are recommended.</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Avoid these dangerous situations!</i></p> | |

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>Please note that suitable emergency stop systems (e.g. systematic shutdown) and restart systems (e.g. correct valve switching sequence, pressure buildup valves) are needed for pneumatic actuators. Unwanted blocking of the compressed air supply can lead to unwanted situations.</i></p> | |




Fig. 5-4 Emergency stop circuit

- A. Compressed air connection A (extend/retract, cf. table)
- B. Compressed air connection B (extend/retract, cf. table)
- 1. 5/2 control valve, bistable
- 2. 3/2 control valve, monostable / emergency stop
- 3. Piloted non-return valve

5.3.4 Adjustment possibilities for the linear unit

The device is always delivered in its respective “maximum stroke” setting. To adjust, proceed as follows:






Fig. 5-5 Adjustment possibilities for the linear unit



- ▶ Loosen the clamping screw (E) (hexagonal socket head) of the stop screw.
- ▶ Adjust the stop screws (C) as needed on one or both sides to limit the stroke.
- ▶ Adjust the shock absorbers (G) (cf. separate chapter 5.3.4.2) and fasten the stop screws again with the clamping screws.
- ▶ In the case of the LSM-4 and LSK-6 it is possible to attach the stop systems on both sides to avoid collisions of the connection cable in the superstructure.
- ▶ In the case of the LSK-4 it is possible to obtain *one* stop block as accessory in order to reposition *one* of the stops (system extended (cf. Accessories 9.2)).

5.3.4.1 Set speed

| | | |
|---|--|----------------|
|  |  | WARNING |
| | <p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p> | |

The speed can be adjusted to the load by an external exhaust regulator (not included in the delivery). If the regulator is set too fast, this will cause hard stopping and bouncing. This can also have a negative effect on the lifetime of the linear unit and even result in destruction of its mechanical components.

5.3.4.2 Set shock absorber

| | | |
|---|--|----------------|
|  |  | WARNING |
| | <p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p> | |



The strength of the shock absorber must be adjusted to the load. If the shock absorber (G) is set too hard, it is possible for the linear unit to bounce and it does not reach end position. If the shock absorber (G) is set too soft, this will cause hard stopping and bouncing. This can also have a negative effect on the lifetime of the linear unit and even result in destruction of its mechanical components.

- ▶ Depending on the mass being moved and the speed, there are kinetic energies in the system that are absorbed by hydraulic shock absorbers.
- ▶ Move the head plate manually to end position and leave it there.
- ▶ Loosen the clamping screw (E) (hexagonal socket head) of the stop screw (cf. sketch in chapter 5.3.4 Adjustment possibilities).
- ▶ To mount the shock absorber (G), screw it into the mount clockwise.
- ▶ Screw in the shock absorber (G) until its housing rests against the stop.
- ▶ Then screw the shock absorber (G) out again by at least half a revolution and clamp it with the clamping screw (E) (hexagonal socket head).
- ▶ The action of the shock absorber can be influenced/set by screwing in or out. This is particularly necessary when shock absorbers that cannot be adjusted externally with an adjusting

screw are used. In this case screw the shock absorber out a little further!

► Proceed in the same way to mount the second shock absorber.

Pressurize the system with compressed air and let the linear unit drive into the end positions. Adjustment is correct when the end positions are reached without visible delay and without bouncing.

| | | |
|---|---|---------------|
|  |  | NOTICE |
| | <p><i>The shock absorbers are pre-set on delivery. It is, however, possible that the damping action needs to be set softer or harder.</i></p> | |






Fig. 5-6 Set shock absorber for STD-14

Set shock absorber harder



Turn the adjusting screw to the right.

Set shock absorber softer

Turn the adjusting screw to the left.

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>Only adjust the damping action with the adjusting screw (STD-14). If there is no adjusting screw available, the shock absorber should be adjusted via the shock absorber stroke.</i></p> | |



5.4 Startup



| | | |
|---|--|----------------|
|  |  | WARNING |
| | <p><i>Risk of injury from moving masses.</i> <i>Make sure that no personnel or foreign objects can be caught by moving parts.</i> <i>Disconnect the linear unit from the compressed air supply.</i></p> <p><i>Otherwise serious injuries or death can result.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |



- ▶ Do not overload the devices.
- ▶ Adjust the stroke length (cf. chapter 5.3.4).
- ▶ Connect all air hoses and signal cables correctly.
- ▶ Pre-set the shock absorbers.
- ▶ Pre-set the sensors.
- ▶ Close all regulators and then open them again by one revolution.
- ▶ Make sure that no personnel or foreign objects can be caught by moving parts.
- ▶ Pressurize your equipment slowly with compressed air. (Extend / Retract, cf. table in chapter 5.3.3.1).
- ▶ Start a trial run.
- ▶ Set the proximity switches (if available).
- ▶ Set the required speed.
- ▶ Set the shock absorbers.
- ▶ End the trial run.



Linear Unit Type: LSM; LSK

5.4.1 Mounting of proximity switches (accessories)

| | | |
|---|---|----------------|
|  |  | WARNING |
| | <p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |

| | | |
|---|---|---------------|
|  |  | NOTICE |
| | <p><i>The standard device does not come with proximity switches. However, to query end positions, it is necessary to retrofit proximity switches. The proximity switches can be obtained separately as accessories.</i></p> | |

| | | |
|--|---|---------------|
|  |  | NOTICE |
| | <p><i>The linear units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.</i></p> | |

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>Make sure that the proximity switches do not extend over the stop surface of the stop screws - this can lead to damage and destruction of parts.</i></p> | |

| Unit | Mounting |
|--|---|
| LSM-3-SM LSM-4-SM LSK-4-SK LSK-4-HK | <p>The proximity switches are mounted in the stop screws.</p> <p>Insert the cylindrical switch into the stop as far as it goes and then lock the switch with the screw (1.5 Nm/size 6 for LSM-3; 2 Nm/size 8). The inside cone fastens the switch in place.</p> <p>In this connection also see chapter 5.3.4 regarding adjustment of the stroke lengths.</p> |
| LSK-6-SK | <p>Insert the proximity switch set and simply fasten the switches with the thumb screws. We offer a fastening set for conventional proximity switches with a diameter of 6.5 mm, cf. chapter 9.2 Accessories.</p> <p>Make sure that the proximity switches do not extend over the stop surface of the stop screws - this can lead to damage and destruction of parts.</p> |

► Connect the proximity switches with the cables.

- Set the proximity switches so that the LED of the switch lights up when the respective end position is reached. Make sure that the switch signal does not set in too soon because otherwise the linear unit will not reach end position.

Technical data

| Type | NSS-O6,5-S-65 | NS-I-04-K/S-27 |
|-------------------------------------|---------------|---|
| Switching distance | 1.5 mm | 0.8 mm |
| Circuit type | PNP | PNP |
| Switching characteristic | NO | NO |
| Supply voltage | 10-30 V DC | 10-30 V DC |
| Current consumption | <10 mA | <10 mA |
| Switching current | Max. 200 mA | Max. 100 mA |
| Switching frequency | Max. 5 kHz | Max. 3 kHz |
| LED | Yes | Yes |
| Protected against polarity reversal | Yes | Yes |
| Short-circuit proof | Yes | Yes |
| Protection | IP 67 | IP 67 |
| Linear unit | LSK-6-SK | LSM-3-SM LSM-4-SM LSK-4-SK LSK4-HK |






Fig. 5-7 Connection diagram for proximity switches

5.4.2 Repair / Replacement of the hydraulic shock absorber

| | | |
|---|---|----------------|
|  |  | WARNING |
| | <p><i>Work may only be carried out by specially trained personnel because the device is pressurized.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p> | |

- Loosen the clamping screw (E) (hexagonal socket head) of the stop screw - this also release the shock absorber for adjustment.




Fig. 5-8 Repair / Replacement of the hydraulic shock absorber



- To dismount the shock absorber (G), screw it out of the mount anticlockwise. Screw in the new shock absorber (G) until its housing rests against the stop. Cf. chapter 5.3.4.2 / Set shock absorber
- Then screw the shock absorber (G) out again by at least half a revolution and clamp it with the clamping screw (E) (hexagonal socket head).
- The action of the shock absorber can be influenced/set by screwing in or out. This is particularly necessary when shock absorbers that cannot be adjusted externally with an adjusting screw are used. In this case screw the shock absorber out a little further!
- Proceed in the same way to replace the second shock absorber.
- Pressurize the system with compressed air and let the linear unit drive into the end positions. Adjustment is correct when the end positions are reached without visible delay and without bouncing.



Technical data

| Type | STD-6-S | STD-8-RS | STD-8-S | STD-14-W |
|--------------------------|-------------|-------------|-------------|-------------|
| Fastening | M6 x 0.5 | M8x1 | M8x1 | M14 x 1 |
| Stroke | 4 mm | 5 mm | 5 mm | 12 mm |
| Impact speed (min./max.) | 1.8-3.5 m/s | 1.8-3.5 m/s | 1.8-3.5 m/s | 0.4-5.0 m/s |
| Absorption | 1.5 Nm | 1.5 Nm | 3 Nm | 30 Nm |
| Damping work max. | 3,200 Nm/h | 5,000 Nm/h | 8,000 Nm/h | 50,000 Nm/h |
| Material | Steel | | | |
| Weight | 0.006 kg | 0.013 kg | 0.012 kg | 0.065 kg |

| Shock absorbers | STD-6-S | STD-8-RS | STD-8-S | STD-14-W |
|--------------------|---------|----------|---------|----------|
| Linear units | | | | |
| LSM-3-SM-X-X-0-0-P | • | | | |
| LSM-4-SM-X-X-0-0-P | | • | | |
| LSK-4-SK-X-X-0-0-P | | | • | |
| LSK-4-HK-X-X-0-0-P | | | • | |
| LSK-6-SK-X-X-0-0-P | | | | • |

6 Maintenance/Serviceing

| | | |
|---|--|----------------|
|  |  | WARNING |
| | <p><i>Disconnect the linear unit from the compressed air supply and lock against reconnection!</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Make sure there are no residual energies present.</i></p> | |

| | | |
|---|--|---------------|
|  |  | NOTICE |
| | <p><i>If you have opted for use with an oil/air mixture, the device should then later not be operated otherwise because the lubricating film could fail.</i></p> | |

Shock absorbers

The hydraulic shock absorbers are wearing parts. They should therefore be inspected at regular intervals (about every 2,000,000 strokes). Defective shock absorbers can cause consequential damage. Our STD14 are repairable, and we therefore recommend you arrange the possibility of repair with our customer service.

Serviceing

After a modification/repair, all moving parts and their guides should be smeared with our special grease.

The seals and the grease inside the linear unit can age depending on use; we therefore recommend that you send the device in to us for servicing every 3 years, after 20,000,000 cycles or should you notice a fault in the movement.

Only clean the linear unit with soft cloths and agents that do not damage the material.

Contact with aggressive media and grinding dust should be avoided.

6.1 Warranty and guarantee conditions

The statutory warranty period of the manufacturer / distributor is 24 months from the date of delivery.

For spare parts, we guarantee delivery according to chapter (see also DIN EN 82079-1).

We grant a warranty of 24 months (from the date of delivery ex works) on the proviso that the device is treated correctly in 1-shift operation and the application and environmental conditions are complied with. This includes replacement or repair of defective parts of Friedemann Wagner GmbH.

Wearing parts (e.g. shock absorbers) are not covered by the warranty.

During the warranty period repairs may only be carried out or authorized by Friedemann Wagner GmbH.

7 Troubleshooting

| Fault | Cause | Correction |
|---|---|---|
| Irregular movement | Regulator is turned in too far | Set regulator correctly |
| | Air ducts are blocked | Clean air ducts with compressed air |
| No movement | Connected incorrectly | Connect compressed air connections correctly |
| | Indexing unit controlled incorrectly | Check program and change |
| | Incorrect switching signal or signal sets in too soon | Set proximity switch correctly, see chapter 5.4.1. |
| | Faulty switching | Interchange compressed air connections and pressurize with compressed air |
| | Regulator is turned in too far | Set regulator correctly |
| Proximity switch emits incorrect signals No switching signal | Proximity switch is set incorrectly | Set proximity switch correctly, see chapter 5.4.1. |
| | Proximity switch is defective | Replace proximity switch, see chapter 5.4.1. |
| End-position stop too hard | Shock absorber (G) is set incorrectly | Set shock absorber (G) correctly, see chapter 5.3.4.2. |
| | Shock absorber (G) is defective | Replace shock absorber (G), see chapter 5.4.2. |
| End position is not reached No switching signal | Shock absorber turned in too far | Mount shock absorber (G) correctly, see chapter 5.4.2 |
| | Pressure too low | Increase air pressure |
| | Load too high | Keep to technical data |

Table 1 Troubleshooting

You can obtain further help from:

Friedemann Wagner GmbH, D-78559 Gosheim / Germany
 Telephone: +49 (0) 7426 / 94900-0
 Fax: +49 (0) 7426 / 94900-9
 Email: info@wagnerautomation.de

8 Dismantling / Disposal

Dismantling

Dismantling work may only be carried out by skilled personnel. Make sure the shutdown procedure is followed before beginning dismantling work.

Further, the following must be followed where applicable / available:

- Release the energy in the pressure accumulator.
- Make sure there are no residual energies in the system anymore.
- Release all tensioned springs.



Disposal

The device is primarily made of steel and to a certain extent also of aluminum (except for the electrical equipment) and is to be disposed of in accordance with local environmental protection regulations applicable **at the time** of disposal.

Dispose of according to properties, existing laws and regulations as, for example:

- electric and electronic scrap (circuit boards), PC system, keyboard, mouse, monitor (according to WEEE regulations);
- batteries, fluorescent lamps/energy-saving lamps (collection points);
- plastics (housing), rubber;
- metal, steel, copper, aluminum (separated by sorts).

All parts touched by media must be decontaminated before disposal. Hazardous substances are to be removed from the device.


For proper disposal of hazardous substances, observe the material safety data sheets (MSDS) and current applicable disposal regulations.

Oils, solvents, cleaning agents and contaminated cleaning materials (brushes, cloths, etc.) must be disposed of according to local regulations, the applicable disposal codes and the information in the manufacturer's material safety data sheets.


9 Spare part lists and accessories

9.1 Spare part lists


LSM-3



LSM-4



LSK-4



LSK-6




Fig. 9-1 Spare part list

9.2 Accessories

The following accessories are available from us for the linear unit.

| Designation | LSM-3-SM | LSM-4-SM | LSK-4-SK LSK-4-HK | LSK-6-SK |
|---|----------------------------|----------------------------|----------------------------|-----------------|
| Centering rings | ZR-3 ZR-4 | ZR-4 | ZR-4 | ZR-6 |
| Proximity switches | NSI-O4-K-27 NSI-O4-S-27 | NSI-O4-K-27 NSI-O4-S-27 | NSI-O4-K-27 NSI-O4-S-27 | NSS-O6,5-S-65 |
| Cables for proximity switches | • | • | • | • |
| Fastening set for conventional proximity switches in the stop screw | - | - | - | BFS-O6,5-ASL-35 |
| Shock absorbers | STD-6-S | STD-8-RS | STD-8-S | STD-14-W |
| 1 stop block LSK-4 | | | • | |
| Face-end stops | - | - | • | - |