

Installation and Operating Instructions

Rotary Indexing Unit

Type: RSE-6 / RSE-9





Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Internet: <http://www.wagnerautomation.de>
Email: info@wagnerautomation.de

Edition 07/2023

Translation of Original Installation and Operating Instructions

	 NOTICE
	<p><i>Important! – Read carefully before use – Keep for future reference!</i></p> <p><i>The installation and operating instructions are an integral part of the device and must be available to the operating and maintenance personnel at all times.</i></p> <p><i>The safety information contained in them must be heeded accordingly.</i></p> <p><i>If the device is resold, these installation and operating instructions must always be delivered with it as well.</i></p> <p><i>The latest version is to be found on the Internet at the manufacturer's website: http://www.wagnerautomation.de</i></p>

Warranty and guarantee conditions:

See chapter 6.1, Warranty and guarantee conditions.

The **warning and safety symbols** are explained in chapters 3.1 and 3.1.1.

Translation

If the device is sold to a country in the EEA, these installation and operating instructions must be translated into the language of the country in which the device is to be used. Should the translated text be unclear, the original installation and operating instructions (German) must be consulted or the manufacturer contacted for clarification.

Copyright

No part of this publication may be reproduced, transmitted, sold or disclosed without prior permission. Damages will be claimed for violations.

All rights reserved.

Document name:

[Dss735 BA_719_Rundschalteinheit_RSE 6-9_31_05-2016_Druckversion _7_2016.doc](#)

1 Contents

1.1 Table of contents

1	Contents	3
1.1	Table of contents	3
1.2	Table of figures	4
1.3	List of tables	4
1.4	Declaration of incorporation	5
2	Overview and intended use	6
2.1	Overview of the device	6
2.2	Intended use	8
2.2.1	Product identification	9
2.2.2	Incorporation information (for the partly completed machinery) for the constructor of the final machinery	9
2.3	Technical data	11
2.3.1	Dimensions and weight	11
2.3.2	Environmental conditions	12
2.3.3	Characteristics	13
2.3.4	General data	14
3	Safety	15
3.1	Notes and explanations	15
3.1.1	Explanation of safety symbols used	16
3.2	Safety precautions (to be carried out by the operator)	17
3.3	Safety inspections and tests	17
4	General warnings	18
4.1	Dangers	18
4.2	Spare and wearing parts	18
5	Installation	20
5.1	Scope of delivery	20
5.2	Transport and packaging	21
5.2.1	Delivery (also of spare and replacement parts)	21
5.2.2	Temporary storage/Storage conditions	22
5.3	Mounting	22
5.3.1	Mounting the rotary indexing unit	22
5.3.2	Mounting of superstructures	24
5.3.3	Connection examples	26
5.3.3.1	Example of standard pneumatic connection	27
5.3.4	Example of pneumatic connection with EMERGENCY STOP circuit	28
5.3.4.1	Adjustment possibilities for the rotary indexing unit	29
5.3.4.2	Set speed	29
5.3.4.3	Set shock absorber	30
5.3.4.3.1	Set pneumatic shock absorber	30
5.3.4.3.2	Set hydraulic shock absorber	31
5.3.4.3.3	Set shock absorber stroke	32
5.4	Startup	33

5.4.1	Mounting of proximity switches (accessories)	34
5.4.2	Replace pneumatic shock absorber with hydraulic shock absorber	36
5.4.3	Repair / Replacement of the hydraulic shock absorber	37
6	Maintenance/Servicing	39
6.1	Warranty and guarantee conditions	40
7	Troubleshooting	41
8	Dismantling / Disposal	42
9	Spare part lists and accessories	43
9.1	Spare part lists RSE-6 and RSE-9	43
9.2	Accessories	44

1.2 Table of figures

Fig. 2-1	Diagram of the parts of the RSE-6 and RSE-9 rotary indexing units with hydraulic or pneumatic shock absorbers	6
Fig. 2-2	Characteristics RSE-6 and RSE-9	13
Fig. 5-1	Scope of delivery of the device	20
Fig. 5-2	Mounting of rotary indexing unit	23
Fig. 5-3	Mounting of superstructures	25
Fig. 5-4	Standard circuit	27
Fig. 5-5	Emergency stop circuit	28
Fig. 5-6	Set speed	29
Fig. 5-7	Set pneumatic shock absorber	30
Fig. 5-8	Set hydraulic shock absorber	31
Fig. 5-9	Set shock absorber stroke	32
Fig. 5-10	Mounting of proximity switches	35
Fig. 5-11	Cover for piston rod	36
Fig. 9-1	Spare part list RSE-6 and RSE-9	43

1.3 List of tables

Table 1	Troubleshooting	41
---------	-----------------	----

1.4 Declaration of incorporation

Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany

Declaration of incorporation

pursuant to the

- **EC Machinery Directive 2006/42/EC**
- **EC EMC Directive 2014/30/EU**

We hereby declare that the design of the

Designation: Rotary Indexing Unit

Type: RSE-X-X-X-X-X-X-P

as delivered complies with the above directives.

Harmonized DIN EN standards applied pursuant to the Official Journals for the directives:

Directive / Standard	Title
DIN EN ISO 82079-1 :2012	Preparation of instructions for use – Structuring, content and presentation – Part 1: General principles and detailed requirements
2006/42/EC	EC Directive: Machinery <i>effective from 2009-12-29</i>
DIN EN ISO 12100 :2010	Safety of machinery – General principles for design – Risk assessment and risk reduction

- This declaration only applies to the rotary indexing unit in the state in which it was placed on the market.
- The essential health and safety requirements according to Annex I of the Machinery Directive were applied and are fulfilled.
- The following chapters in Annex I of the Machinery Directive 2006/42/EC were considered in the risk assessment:
1.1.2, 1.1.3, 1.1.5, 1.2.6, 1.3.1, 1.3.2, 1.3.3, 1.3.4, 1.3.6, 1.3.7, 1.3.8.2, 1.3.9,
1.4.1, 1.4.2.1, 1.5.3, 1.5.4, 1.5.9, 1.5.11, 1.5.15, 1.6.1, 1.6.4, 1.7.1, 1.7.2, 1.7.3, 1.7.4.
- The special technical file according to Annex VII B was compiled and will be presented to the competent national authorities in electronic form on demand.
- **The rotary indexing unit may not be put into service until the final machinery into which it is incorporated has been declared in conformity with the provisions of the directives.**
- The person authorized to compile the technical documentation is:
Name: Mr. Andreas Wagner
Address: Robert-Bosch-Straße 5, D-78559 Gosheim / Germany

Gosheim, April 2017

Authorized Signature
(A. Wagner, Managing Director)

2 Overview and intended use

2.1 Overview of the device






Fig. 2-1 Diagram of the parts of the RSE-6 and RSE-9 rotary indexing units with hydraulic or pneumatic shock absorbers

The rotary indexing unit RSE-6 / RSE-9 consists of the following main components:	
<p>(A) Compressed air connection A (unlock and turn)</p> <p>(B) Compressed air connection B (lock and start position)</p> <p>(C) Mounting hole</p> <p>(D) Mounting hole for proximity switch</p> <p>(E) Screw cap</p> <p>(F) Hydraulic shock absorber cover</p> <p>(G) Hydraulic shock absorber</p> <p>(H) Threaded hole</p> <p>(I) Pin bore</p> <p>(J) Central bore</p> <p>(K) Indexing plate</p> <p>(L) Regulator</p>	<p>(M) Index/Anti-turn device</p> <p>(N) Housing</p> <p>(O) Stop screw</p> <p>(P) Hexagonal nut</p> <p>(Q) O-rings</p> <p>(S) Pneum. shock absorber cover complete</p> <p>(Y) Output switching signal</p> <p>(Z) Centering ring</p>

2.2 Intended use



The rotary indexing units were developed to turn components or superstructures by a defined angle. They are suitable for assembly work and processing of components in a rotary indexing system.

This device was developed, designed and built exclusively for industrial and light-industrial use. Private use is prohibited.

	 DANGER
	<p><i>This device is intended solely for the purpose described above. Any other use or modification of the device without the written consent of the manufacturer is deemed improper.</i></p> <p><i>Modification without written agreement will lead to serious to deadly injuries.</i></p> <p><i>The manufacturer accepts no liability for resultant damage. The risk is borne solely by the operator. The device may only be put into operation when it has been ensured that all safety devices have been installed and are fully functional.</i></p>

Proper use of the device in accordance with its intended purpose includes compliance with the manufacturer's instruction handbooks and operating manuals and performance of all specified maintenance and service work.

Foreseeable misuse:

	 NOTICE
	<p><i>Products that could form explosive dust/air or gas/air mixtures may not be processed in critical concentrations (above LEL)! The device does not fulfil any EX requirements and may therefore also not be installed and operated in ATEX zones!</i></p> <p><small>*) LEL = Lower Explosive Limit</small></p>

The device is not suitable for use in machining operations, especially of aluminum, titanium and magnesium.

Rotary Indexing Unit Type: RSE-6 / RSE-9

2.2.1 Product identification

The type key is laser-engraved on the connection side of the rotary indexing unit. The following table explains the type key:

Module	Design size	Version	Partition	Shock absorber	Energy feedthrough	Drive
RSE	6 9	R L	4 . . 24	H P	0-0	P
		R= right L= left	RSE-6 max. 18	H= hydraulic P= pneumatic	0- = pneumatic 0 = electric	P= pneumatic

2.2.2 Incorporation information (for the partly completed machinery) for the constructor of the final machinery

- The central bore (J) enables easy centering of all superstructures. The superstructures are fastened with the pin bores (I).
- The rotary indexing units are delivered wither with a hydraulic or pneumatic shock absorber.
- Control is effected via a 4/2 or 5/2 directional-control valve (not included in the delivery).
- The rotary indexing units are largely configurable.
- Clockwise or anti-clockwise
- The speed can be adjusted freely with an integrated non-return regulator valve (L).
- The compressed air escapes via an air duct when end position is reached and flows to the output "Switch signal" (Y). If the switch signal is not needed, the connection must be closed.
- The central bore (J) of the rotary indexing unit is fixed so that a screw column can be fastened for fastening of work units.
- A supply air regulator can be mounted at the compressed air connection B (B) for softer locking and thus noise reduction. It must then be ensured that the regulator is not closed too far as this could lead to malfunctions. The return stroke slows down as throttling increases (the cycle time is lengthened).
- No regulator may be used at compressed air connection A (A). There is a regulator integrated in the rotary indexing unit for setting of the rotational speed (L).

- The formula for calculation of the switching times is:
RSE-6 *Switching time (rpm)* = $[50 + (n-4) \times 4]$
RSE-9 *Switching time (rpm)* = $[40 + (n-4) \times 4]$

where n= number of partitions.

After considering all these points, the integrator of the final machinery can put this device into service as a safe device.

He must supply overall instructions for use and a declaration of conformity for the complete machinery and affix a type plate with CE marking to the machinery. The responsibility for the risk assessment for the complete machinery lies internally with the integrator.

Rotary Indexing Unit Type: RSE-6 / RSE-9

2.3 Technical data

2.3.1 Dimensions and weight

Type	RSE-6	RSE-9
Indexing accuracy	± 0.03 mm at Ø 120	± 0.03 mm at Ø 180
Torque locked (static)	27.5 Nm	137 Nm
Lateral force (static)	600 N	1200 N
Max. clamping weight	25 kg	70 kg
Actuations/minute	50 – 110	40 – 110
Connection	R 1/8"	
Partition	4-18	4-24
Weight	8.5 kg	27.0 kg
Torque (theoretical)	12 Nm (16 Nm)	30 Nm (42 Nm)
Direction of rotation	Clockwise or anti-clockwise	
Installation position	Horizontal	
Drive	Compressed air 5-8 bar, constant, filtered (10 µm) and dry, lubricated or unlubricated	
Control	4/2 or 5/2 directional-control valve	
Housing material	High strength aluminum, anodized	
Plate material	Steel, burnished	
Axial run-out of plate	0.04 mm	
Sound pressure level	≤ 70 db	
Cylinder diameter	32 mm	40 mm
Concentricity of central bore	0.03 mm	
Plane parallelism housing – plate	0.06 mm	
Axial load of plate under pressure dynamic	250 N	700 N
Axial load of plate under pressure (static) on even loading	20 kN (max. Ø 110)	35 kN (max. Ø 160)
Tilting moment	230 Nm	950 Nm
Max. moment of inertia (pneumatic/hydraulic)	405/1,540 kg/cm ²	2,734/11,000 kg/cm ²
Air consumption	76.4 cm ³ /cycle	221 cm ³ /cycle



2.3.2 Environmental conditions

- Operation only in closed rooms and low-vibration environments (no potentially explosive or condensing atmospheres).
- No operation in environments with spray water, vapors, process dusts or abrasion dusts.
- Rotary indexing units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.
- The rotary indexing units are only suitable for use in environments with spray water to a limited extent. It might be necessary to protect them against ingressing spray water with a suitable cover.

2.3.3 Characteristics

Belastungsdiagramme RSE-6

Load diagrams RSE-6



Belastungsdiagramme RSE-9

Load diagrams RSE-9





Fig. 2-2 Characteristics RSE-6 and RSE-9

2.3.4 General data

Operating temperature range:

Temperature range device:

+ 5° ... + 65° C

Relative air humidity:

max. 70 %, non-condensing

Storage conditions:

Minimum temperature:

- 10° C

Maximum temperature:






+ 50° C

Relative air humidity:



max. 70 %, non-condensing

3 Safety

3.1 Notes and explanations

	<div data-bbox="580 450 667 517"></div> <div data-bbox="667 450 1442 517">DANGER</div> <p>“DANGER” warns of dangerous situations. Avoid these dangerous situations!</p> <p>Otherwise serious injuries or death will result.</p>
	<div data-bbox="580 712 667 779"></div> <div data-bbox="667 712 1442 779">WARNING</div> <p>“WARNING” warns of dangerous situations. Avoid these dangerous situations!</p> <p>Otherwise serious injuries or death can result.</p>
	<div data-bbox="580 974 667 1041"></div> <div data-bbox="667 974 1442 1041">CAUTION</div> <p>“CAUTION” in combination with the warning symbol warns of dangerous situations. Avoid these dangerous situations!</p> <p>Otherwise minor or light injuries could result.</p>
	<div data-bbox="580 1236 667 1303"></div> <div data-bbox="667 1236 1442 1303">NOTICE</div> <p>“NOTICE” gives recommendations on how to proceed. Ignoring these recommendations will not lead to personal injuries.</p> <p>Follow the recommendations to avoid damage to the unit and problems in general!</p>
	<div data-bbox="580 1520 667 1588"></div> <div data-bbox="667 1520 1442 1588">NOTICE</div> <p>References to installation and operating instructions / documentation are marked with a book symbol (see external documentation).</p> <p>Follow the recommendations to avoid damage to the unit and problems in general!</p>

3.1.1 Explanation of safety symbols used

	<div data-bbox="584 322 663 389"></div> <div data-bbox="995 338 1126 371">DANGER</div> <p>Crushing hazards, dangers of injuries to the hands (closing movements of mechanical parts).</p> <p>Ignoring this warning will result in serious injuries or death. Do not carry out any manual work on such parts during movements.</p>
	<div data-bbox="584 613 663 680"></div> <div data-bbox="991 629 1131 663">WARNING</div> <p>Mandatory: Safety boots must be worn.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers to the lower limbs.</p>
	<div data-bbox="584 864 663 931"></div> <div data-bbox="991 880 1131 913">WARNING</div> <p>Mandatory: Protective gloves must be worn.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers to the hands.</p>
	<div data-bbox="584 1115 663 1182"></div> <div data-bbox="991 1131 1131 1164">WARNING</div> <p>Mandatory: Hands must be washed.</p> <p>Ignoring this warning could result in serious injuries or death. Take note of the dangers due to deficient hygiene.</p>
	<div data-bbox="584 1366 663 1433"></div> <div data-bbox="1007 1382 1118 1415">NOTICE</div> <p>The environment sign marks actions to protect the environment (warning of environmental pollution, in the chapter Disposal).</p> <p>Damage to the environment will result if ignored. Improper disposal can result in serious damage to the environment.</p>

3.2 Safety precautions (to be carried out by the operator)

- ▶ The rotary indexing units may only be installed, serviced and modified by qualified skilled personnel. This personnel must have read and understood the operating instructions.
- ▶ The energy and compressed air supply must be disconnected from the rotary indexing unit before any service, maintenance or modification work. Make sure there are no residual energies present.
- ▶ Only use the rotary indexing units if they are in perfect technical condition and do not carry out any unauthorized modifications.
- ▶ The rotary indexing units can be heavy. Secure them so that they cannot fall down.
- ▶ In the event of an emergency, malfunction or other irregularity, switch off the rotary indexing unit, disconnect it from the energy and compressed air supply and lock against reconnection.
- ▶ Carry out a visual inspection of the compressed air lines regularly. Operation with damaged compressed air lines is prohibited.
- ▶ Make sure that the technical specifications and environmental conditions specified in the product documentation are adhered to.
- ▶ The rotary indexing unit may only be operated in accordance with its intended use.
- ▶ Take note of the valid regulations on accident prevention and environmental protection.
- ▶ Implement the safeguards required by EC directives.
- ▶ Pressurize your complete equipment with compressed air slowly to avoid uncontrolled movements.
- ▶ Only put your equipment into service if you are sure that no personnel or foreign objects can be caught by the moving parts.

3.3 Safety inspections and tests



Factory inspections and tests by the manufacturer.

1. Risk assessment according to Machinery Directive 2006/42/EC (to Annex I) and to DIN EN ISO 12100:2010.

4 General warnings

4.1 Dangers

The safety systems and safety instructions described in these installation and operating instructions are to be heeded accordingly.



		DANGER
	<p><i>Pay attention to the possible danger of injuries to the hands and/or body when carrying out adjustment, maintenance and repair work!</i></p> <p>Otherwise serious injuries or death will result.</p> <p><i>The machine builder must implement safety equipment to ensure safe operation.</i></p>	



4.2 Spare and wearing parts

Spare parts and accessories that have not been supplied by us have also not been tested and approved by us. The fitting and/or use of such products could therefore negatively affect the design characteristics of your device.

We accept no liability whatsoever for damage arising from the use of non-original parts and accessories.

Standard parts can be bought through the specialized trade.

		NOTICE
	<p>Part lists and technical data sheets are to be found in the technical reference documents.</p> <p>Otherwise the unit will be damaged.</p> <p><i>Damage can arise if the attached technical reference documents are ignored.</i></p>	

		NOTICE
	<p>Lists of spare parts and wearing parts are to be found in the technical reference documents.</p> <p>Otherwise the unit will be damaged.</p> <p><i>Damage can arise if the attached technical reference documents are ignored.</i></p>	

Service

When necessary, these parts can be obtained from:

Friedemann Wagner GmbH
Robert-Bosch-Straße 5
D-78559 Gosheim / Germany
Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Email: info@wagnerautomation.de

5 Installation

5.1 Scope of delivery




Fig. 5-1 Scope of delivery of the device

The scope of delivery comprises:

- 1 Rotary indexing unit including base construction
- 2 These installation and operating instructions with declaration of incorporation
- 3 Centering ring
- 4 Cardboard packaging

5.2 Transport and packaging

The customer is sent a specification of the scope of delivery before shipment begins. It contains details on:

- date of delivery,
- number and type of transport units.

The devices are carefully inspected and packed before shipment, but it is nevertheless still possible that they might become damaged during transit.

5.2.1 Delivery (also of spare and replacement parts)

Receiving inspection:

- Check the shipment against the delivery note to ensure that it is complete!

If the packaging is damaged

- Check the shipment itself for damage (visual inspection)!

Complaints

If the shipment was damaged during transit:

- Immediately contact the last carrier!
- Keep the packaging material (for possible inspection by the carrier or for return shipment).



Packaging for return shipment

Use the original packaging material as far as possible.

5.2.2 Temporary storage/Storage conditions

The freight packaging of the device and spare and replacement parts is designed for a storage period of 3 months from delivery.

After dismantling of the device, it must be stored properly to enable reuse.



		NOTICE
	<p><i>Temporary storage: Store with desiccant in a dry factory hall.</i></p> <p>Otherwise the unit will be damaged.</p> <p><i>Moisture could penetrate into the device and cause major damage.</i></p>	

Storage conditions



- See chapter 2.3.4, Technical data
- No direct sunlight.
- No exposure to direct rain, condensation, water.

5.3 Mounting

5.3.1 Mounting the rotary indexing unit

		NOTICE
	<p><i>The rotary indexing units are suitable solely for horizontal mounting.</i></p>	

- Place at least 2 diagonally offset centering rings (Z) (are included in the delivery) in the holes (C) provided.
- Screw the rotary indexing unit tight with the screws (W).

		NOTICE
	<p><i>If a centering ring (Z) is stuck in a hole, you can remove it from the hole easily with a threaded screw. The centering rings have an internal thread specifically for this purpose. Simply screw a suitable screw (M8 for ZR-6 and M10 for ZR-9) into the thread of the centering ring and pull the screw plus centering ring out of the hole.</i></p>	






Fig. 5-2 Mounting of rotary indexing unit

	RSE-6	RSE-9
Recommended screw length (W)	M6 x 25 mm	M8 x 65 mm

5.3.2 Mounting of superstructures

		WARNING
	<p><i>Disconnect the rotary indexing unit from the compressed air supply and lock against reconnection.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

- ▶ Center the superstructures in the central bore (J) and the pin bore (I).
- ▶ Fasten the superstructures with screws (X) in the threaded holes (C) provided.
- ▶ If you need to fabricate own additional bores, we recommend you contact us.










Fig. 5-3 Mounting of superstructures

	RSE-6	RSE-9
Effective thread length (H)	9 mm	12 mm

5.3.3 Connection examples

		WARNING
	<p>Disconnect the rotary indexing unit from the compressed air supply and lock against reconnection.</p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	
		NOTICE
	<p><i>The following figures show connection examples and illustrate how the rotary indexing unit can be connected.</i></p>	
		NOTICE
	<p><i>A function check must be carried out with compressed air after connection.</i></p>	

5.3.3.1 Example of standard pneumatic connection








Fig. 5-4 Standard circuit

- A. Compressed air connection A (unlock and turn)
- B. Compressed air connection B (lock and return stroke)
- Y Control air valve return
- 1. Proximity switch query blocked
- 2. 5/2 control valve pneumatic return

5.3.4 Example of pneumatic connection with EMERGENCY STOP circuit

	 WARNING
	<p><i>In the event of a sudden loss of pressure the payload can drop uncontrolled into one end position. To prevent this, piloted non-return valves are recommended.</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Avoid these dangerous situations!</i></p>

	 NOTICE
	<p><i>Please note that suitable emergency stop systems (e.g. systematic shutdown) and restart systems (e.g. correct valve switching sequence, pressure buildup valves) are needed for pneumatic actuators. Unwanted blocking of the compressed air supply can lead to unwanted situations.</i></p>






Fig. 5-5 Emergency stop circuit

- A. Compressed air connection A (unlock and turn)
- B. Compressed air connection B (lock and return stroke)
- Y control air valve control
- 1. Proximity switch, query blocked
- 2. 5/2 control valve, bistable, pneum. return
- 3. 3/2, monostable // emergency stop
- 4. non-return valve (piloted)

5.3.4.1 Adjustment possibilities for the rotary indexing unit

The speed and damping action must be adjusted to each other such that the movement is decelerated softly. The setting depends on the cycle times that are to be achieved and what weight is to be turned on the indexing plate (K).

5.3.4.2 Set speed

		WARNING
	<p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p>	

The speed must be adjusted to the load. If the regulator (L) is set too slow, the indexing plate (K) needs too long to reach the end position. If the regulator (L) is set too fast, this will cause hard stopping and bouncing. This can also have a negative effect on the lifetime of the rotary indexing unit and even result in destruction of its mechanical components.




Fig. 5-6 Set speed



Increase speed

Turn the regulator screw (L) to the left.



Decrease speed

Turn the regulator screw (L) to the right.



5.3.4.3 Set shock absorber

		WARNING
	<p><i>Take special care whenever carrying out adjustment work and keep sufficiently far away from danger zones.</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Wear personal protective equipment such as gloves or safety glasses if necessary.</i></p>	

The strength of the shock absorber must be adjusted to the load. If the damping is set too hard, it is possible for the indexing plate (K) to bounce and it takes too long for it to reach end position. If the damping is set too soft, this will cause hard stopping and bounding. This can also have a negative effect on the lifetime of the rotary indexing unit and even result in destruction of its mechanical components.

		NOTICE
	<p><i>The shock absorbers are pre-set on delivery. It is, however, possible that the damping action needs to be set softer or harder.</i></p>	

5.3.4.3.1 Set pneumatic shock absorber

		NOTICE
	<p><i>Damping via the pneumatic shock absorber is completely wear-free.</i></p>	




Fig. 5-7 Set pneumatic shock absorber



Set shock absorber harder

Turn the adjusting screw to the right (into the housing).

Set shock absorber softer

Turn the adjusting screw to the left (out of the housing).

5.3.4.3.2 Set hydraulic shock absorber

		NOTICE
	<p><i>It is only possible to set the shock absorber with the regulating screw in the RSE-6. Shock absorption in the RSE-9 rotary indexing unit is set with the stroke of the shock absorber.</i></p>	






Fig. 5-8 Set hydraulic shock absorber

Set shock absorber harder

Turn the adjusting screw to the right (into the housing).

Set shock absorber softer

Turn the adjusting screw to the left (out of the housing).

		NOTICE
	<p><i>The shock absorber must not lie on the rack. In such a case, turn out again by at least a quarter of a revolution and then lock with the nut.</i></p>	

5.3.4.3.3 Set shock absorber stroke




Fig. 5-9 Set shock absorber stroke



Lengthen stroke

Turn the complete shock absorber further into the housing. This makes damping harder.

Reduce stroke










Turn the complete shock absorber out of the housing a little. This makes damping softer.

5.4 Startup

		WARNING
	<p><i>Risk of injury from rotating masses. Make sure that no personnel or foreign objects can be caught by moving parts. Disconnect the rotary indexing unit from the compressed air supply.</i></p> <p><i>Otherwise serious injuries or death can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	

- ▶ Do not overload the devices.
- ▶ Connect all air hoses and signal cables correctly.
- ▶ Pre-set the shock absorbers.
- ▶ Pre-set the sensors.
- ▶ Close all regulators and then open them again by one revolution.
- ▶ Make sure that no personnel or foreign objects can be caught by moving parts.
- ▶ Pressurize your equipment slowly with compressed air.
- ▶ Start a trial run.
- ▶ Set the proximity switches (if available).
- ▶ Set the required rotational speed.
- ▶ Set the shock absorbers.
- ▶ End the trial run.

5.4.1 Mounting of proximity switches (accessories)

	<div data-bbox="580 322 660 389"></div> <div data-bbox="986 338 1134 367">WARNING</div> <p>Disconnect the rotary indexing unit from the compressed air supply and lock against reconnection.</p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>
	<div data-bbox="580 613 660 680"></div> <div data-bbox="995 629 1114 658">NOTICE</div> <p><i>The standard device does not come with proximity switches. However, to query indexing, it is necessary to retrofit proximity switches. The proximity switches can be obtained separately as accessories.</i></p>
	<div data-bbox="580 893 660 960"></div> <div data-bbox="995 909 1114 938">NOTICE</div> <p><i>The rotary indexing units with proximity switches should not be used in areas with static discharges, high-frequency oscillations or strong magnetic fields. Otherwise it can happen that the proximity switches for recognition of the end positions deliver wrong signals.</i></p>
	<div data-bbox="580 1218 660 1285"></div> <div data-bbox="995 1234 1114 1263">NOTICE</div> <p>The proximity switch merely queries locked position.</p>
	<div data-bbox="580 1420 660 1487"></div> <div data-bbox="995 1435 1114 1464">NOTICE</div> <p>The anti-turn device may not lie on the housing when in locked state and may therefore not be adjusted. <i>It is already pre-set such that the proximity switch switches in the right moment.</i></p>







Fig. 5-10 Mounting of proximity switches

- Fasten the proximity switch at the housing (N) or the anti-turn device (M). The necessary bores (D) are already available.
- Connect the proximity switches with the cables.

Technical data

Type	NSI-Q8-M
Switching distance	1.5 mm
Circuit type	PNP
Switching characteristic	NO
Supply voltage	10-30 V DC
Current consumption	<10 mA
Switching current	100 mA to max. 200 mA
Switching frequency	Max. 5 kHz
LED	Yes
Protected against polarity reversal	Yes
Short-circuit proof	Yes
Protection	IP 65/ IP 67

5.4.2 Replace pneumatic shock absorber with hydraulic shock absorber

	<div style="background-color: orange; padding: 5px; text-align: center;">WARNING</div> <p><i>Disconnect the rotary indexing unit from the compressed air supply and lock against reconnection!</i></p> <p>Otherwise light to serious injuries can result.</p> <p><i>Avoid these dangerous situations!</i></p>
	<div style="background-color: blue; color: white; padding: 5px; text-align: center;">NOTICE</div> <p><i>The pneumatic shock absorbers do not suffice for some applications. In such cases a hydraulic shock absorber can be retrofitted.</i></p>
	<div style="background-color: blue; color: white; padding: 5px; text-align: center;">NOTICE</div> <p><i>A STD cover (F) is needed for mounting of the shock absorber.</i></p>

- Unscrew the end-position shock absorber cover (S).
- The contact surface of the new shock absorber cover (F) must correspond to that of the old shock absorber cover. Machine the new screw cover to make it fit the old cover (hollowed or turned, see accompanying sketch).





Cover for piston rod “Hollowed” version	Cover for piston rod “Recessed” version
<p style="text-align: center;">Please adapt dismounted cap</p>  <p style="text-align: center;">RSE-6 Ø32,5 RSE-9 Ø40,5</p>	<p style="text-align: center;">Please adapt dismounted cap</p>  <p style="text-align: center;">RSE-6 Ø31 RSE-9 Ø39</p>

Fig. 5-11 Cover for piston rod

- ▶ Screw the STD cover (F) into the housing. Make sure that the O-ring (Q) is fitted correctly.
- ▶ Pressurize the compressed air connection A (A) with compressed air until the rack is in end position.
- ▶ Screw in the shock absorber (G) until its housing rests on the rack.
- ▶ Then screw the shock absorber out again by half a revolution and lock it with the nut. Make sure that the seal ring is positioned under the nut.

5.4.3 Repair / Replacement of the hydraulic shock absorber

		WARNING
	<p><i>Work may only be carried out by specially trained personnel because the device is pressurized.</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Avoid these dangerous situations!</i></p>	





- ▶ To mount the shock absorber (G), pressurize the compressed air connection A (A) with compressed air until the rack is in end position.
- ▶ To dismount the shock absorber (G), loosen the hexagonal nut (P) and unscrew it.
- ▶ Screw in the shock absorber (G) until its housing rests on the rack.
- ▶ Then screw the shock absorber (G) out again by half a revolution and lock it with the hexagonal nut (P). Make sure that the seal ring (Q) is positioned under the nut. See chapter 5.3.4.3 for information on fine adjustment of the shock absorber (G).

Technical data

Type	STD-14-H (RSE-6)	STD-25-W (RSE-6*)	STD-25-M (RSE-9)
Fastening	M14 x 1	M25 x 1.5	M25 x 1.5
Stroke	12 mm	25 mm	25 mm
Impact speed (min./max.)	0.2-2 m/s	1.8-4 m/s	0.8-2.2 m/s
Absorption	-30 Nm	-100 Nm	-210 Nm
Damping work	- Max. 50,000 Nm/h	- Max. 80,000 Nm/h	- Max. 120,000 Nm/h
Material	Steel		
Weight	0.065	0.3 kg	0.3 kg

***RSE-6 with special shock absorber cover 40 x 25**

6 Maintenance/Serviceing

	<div data-bbox="582 365 662 432"></div> <div data-bbox="986 380 1133 414">WARNING</div> <p><i>Disconnect the rotary indexing unit from the compressed air supply and lock against reconnection!</i></p> <p><i>Otherwise light to serious injuries can result.</i></p> <p><i>Make sure there are no residual energies present.</i></p>
	<div data-bbox="582 674 662 741"></div> <div data-bbox="997 689 1114 723">NOTICE</div> <p><i>If you have opted for use with an oil/air mixture, the device should then later not be operated otherwise because the lubricating film could fail.</i></p>

Shock absorbers

The hydraulic shock absorbers are wearing parts. They should therefore be inspected at regular intervals (about every 2,000,000 strokes). Defective shock absorbers can cause consequential damage. Our STD14 are repairable, and we therefore recommend you arrange the possibility of repair with our customer service.

Servicing

After a modification, all moving parts and their guides should be smeared with our special grease.

The seals and the grease inside the rotary indexing unit can age depending on use; we therefore recommend that you send the device in to us for servicing every 3 years, after 20,000,000 cycles (RSE 6) or 10,000,000 cycles (RSE-9) or should you notice a fault in the rotational movement.

Only clean the rotary indexing unit with soft cloths and agents that do not damage the material.

Contact with aggressive media and grinding dust should be avoided.

6.1 Warranty and guarantee conditions

The statutory warranty period of the manufacturer / distributor is 24 months from the date of delivery.

For spare parts, we guarantee delivery according to chapter (see also DIN EN 82079-1).

We grant a warranty of 24 months (from the date of delivery ex works) on the proviso that the device is treated correctly in 1-shift operation and the application and environmental conditions are complied with. This includes replacement or repair of defective parts of Friedemann Wagner GmbH.

Wearing parts (e.g. shock absorbers) are not covered by the warranty.

During the warranty period repairs may only be carried out or authorized by Friedemann Wagner GmbH.

7 Troubleshooting

Fault	Cause	Correction
Irregular rotational movement	Regulator is turned in too far	Set regulator correctly, see chapter 5.3.4.2.
	Air ducts are blocked	Clean air ducts with compressed air
No movement of the indexing plate Indexing plate does not lock in position	Rotary indexing unit connected incorrectly	Connect compressed air connections correctly, see chapter 5.3.3.
	Rotary indexing unit controlled incorrectly	Check program and change
	Incorrect switching signal or signal sets in too soon	Check proximity switch, see chapter 5.4.1.
	Regulator is turned in too far	Set regulator correctly, see chapter 5.3.4.2.
	Rack lying on shock absorber	Adjust shock absorber Cf. chapter 5.3.4.3.3
	Anti-turn device lying on housing	Check
Proximity switch emits incorrect signals No switching signal	Proximity switch is set incorrectly	Check proximity switch, see chapter 5.4.1.
	Proximity switch is defective	Replace proximity switch, see chapter 5.4.1.
End-position stop too hard	Shock absorber (G) is set incorrectly	Set shock absorber (G) correctly, see chapter 5.3.4.3.
	Shock absorber (G) is defective	Replace shock absorber (G), see chapter 5.4.3.
Slow movement of the indexing plate into end position or end position not reached when using pneumatic shock absorbers	The grease has blocked up the air duct inside, too much grease in the pneumatic shock absorber	Open the shock absorber cover 38 and remove the excess grease at the cover and in the cylinder bore of the rack

Table 1 Troubleshooting

You can obtain further help from:

Friedemann Wagner GmbH, D-78559 Gosheim / Germany
Telephone: +49 (0) 7426 / 94900-0
Fax: +49 (0) 7426 / 94900-9
Email: info@wagnerautomation.de

8 Dismantling / Disposal

Dismantling

Dismantling work may only be carried out by skilled personnel. Make sure the shutdown procedure is followed before beginning dismantling work.

Further, the following must be followed where applicable / available:

- Release the energy in the pressure accumulator.
- Release all tensioned springs.



Disposal

The device is primarily made of steel and to a certain extent also of aluminum (except for the electrical equipment) and is to be disposed of in accordance with local environmental protection regulations applicable **at the time** of disposal.

Dispose of according to properties, existing laws and regulations as, for example:

- electric and electronic scrap (circuit boards), PC system, keyboard, mouse, monitor (according to WEEE regulations);
- batteries, fluorescent lamps/energy-saving lamps (collection points);
- plastics (housing), rubber;
- metal, steel, copper, aluminum (separated by sorts).

All parts touched by media must be decontaminated before disposal. Hazardous substances are to be removed from the device.

For proper disposal of hazardous substances, observe the material safety data sheets (MSDS) and current applicable disposal regulations.

Oils, solvents, cleaning agents and contaminated cleaning materials (brushes, cloths, etc.) must be disposed of according to local regulations, the applicable disposal codes and the information in the manufacturer's material safety data sheets.

9 Spare part lists and accessories

9.1 Spare part lists RSE-6 and RSE-9




Fig. 9-1 Spare part list RSE-6 and RSE-9

9.2 Accessories

The following accessories are available from us for the rotary indexing unit.

Designation	Type	Suitable for RSE-
Wearing part set	VT	6/9
Shock absorbers	STD	6/9
Proximity switches	NS	6/9
Cables for proximity switches	SK	6/9
Centering rings	ZR	6/9
Screw column	ES	6/9
Clamping piece	KL-6-ES	6
Clamping piece	KL-9-ES	9
Cover for shock absorbers	STD-40-14	6
	STD-40-25	6
	STD-52-25	9
O-rings for shock absorbers	Cf. spare parts list	6/9